



## **USER MANUAL**

*rev. 1.22.02*

If a more detailed description (supplement) can be found elsewhere in this document, the following symbols are used:

 *to be explained*

 *already explained*



*Note (a symbol put in the margin)*

*Proxima IP PBX Server, Proxima plus IP PBX Server,*

*Libra PBX Server, Libra STD PBX Server*

*as well as PLATAN ProximaWeb, LibraWeb and LibraPC*

*are products manufactured by:*

*PLATAN® Sp. z o.o. sp.k. 81-855 Sopot, ul. Platanowa 2, Poland*

*tel. +48 58 555 88 00, fax +48 58 555 88 01*

*e-mail: [export@platan.pl](mailto:export@platan.pl), [www.platan.eu](http://www.platan.eu)*

*technical support and maintenance tel. +48 58 555 88 88*

*All rights reserved.*

Sopot, December 10<sup>th</sup>, 2015

# Table of Contents

<b>1. Introduction .....</b>	<b>7</b>
1.1. Server programming .....	8
1.2. List of acoustic signals within the server .....	10
<b>2. Access to the services offered by the server .....</b>	<b>12</b>
<b>3. Making calls.....</b>	<b>13</b>
3.1. Internal calls.....	13
3.1.1         How to make an internal call .....	13
3.2. External calls .....	14
3.3. Video calls .....	15
3.3.1         Internal video calls.....	15
3.3.2         External video calls.....	15
<b>4. Services offered by the server .....</b>	<b>17</b>
4.1. Services connected with incoming calls .....	17
4.1.1         Analogue trunk lines .....	17
4.1.2         Call queuing.....	18
4.1.3         ISDN trunk lines .....	19
4.1.4         Automatic Call Distribution – ACD.....	19
4.1.5         Call transferring .....	20
4.1.6         Return calls (consultations).....	21
4.1.7         Offering an external call to an engaged user .....	22
4.1.8         Transferring an external call to an engaged user .....	23
4.1.9         HOLD – external call hold.....	23
4.1.10         Transferring a call to another trunk line .....	25
4.1.11         Return external call .....	25
4.1.12         Call Through.....	27
4.1.13         Capturing and returning calls .....	27
4.1.14         Capturing external calls .....	28
4.1.15         Unconditional call forwarding to another telephone - CFU (I'm there) .....	28
4.1.16         Unconditional call forwarding to a selected extension – CFU (I'm here) .....	29
4.1.17         Call forwarding when my number is busy (CFB).....	30
4.1.18         Call forwarding when my telephone fails to answer (CFNA) .....	31
4.1.19         Call forwarding when my VoIP phone is not reachable (CFNR) .....	33
4.1.20         Logging into and out of the Hunt Group .....	34
4.2. Services connected with outgoing calls .....	36
4.2.1         Limiting the duration of external calls .....	36
4.2.2         Direct access to emergency telephone numbers .....	36
4.2.3         External calls through selected trunk lines.....	36
4.2.4         Outgoing external calls with CLIR .....	37
4.2.5         Least Cost Routing – LCR service .....	38
4.2.6         Booking a trunk line call.....	39
4.2.7         Booking a call to an engaged extension .....	40
4.2.8         Call booking through a secretary .....	40
4.2.9         Group call – Hunt Groups.....	41
4.2.10         Calling onto the proprietary phone speaker.....	42
4.2.11         Redialling the last dialled external number .....	42
4.2.12         Booking a call to the last dialled external number.....	43
4.2.13         Booking a call to any external number.....	44

4.2.14	Booking a call to any external number at a specific time .....	45
4.2.15	Speed dialling .....	46
4.2.16	Virtual extensions .....	47
4.2.17	Blocking outgoing external calls from the phone .....	48
4.2.18	Logging a virtual extension for the duration of a single external call.....	49
4.2.19	Notes on the functionality of the virtual extensions .....	50
4.2.20	Analogue FLASH on trunk lines.....	51
<b>4.3.</b>	<b>Conferences.....</b>	<b>52</b>
4.3.1	Conference rooms .....	52
4.3.1.1	Types of conference rooms .....	52
4.3.1.2	Conference room reservation .....	54
4.3.1.3	Checking active reservations.....	55
4.3.1.4	Deleting reservations.....	55
4.3.1.5	Entrance to the conference room.....	56
4.3.2	Internal conference for 8 extension users.....	57
4.3.3	Conference calls with outside party .....	58
4.3.4	Two outside parties – one extension user conference.....	59
4.3.5	CIRCULAR conference.....	60
<b>4.4.</b>	<b>Additional server functions available from the telephone .....</b>	<b>61</b>
4.4.1	Wake-up call (reminder).....	61
4.4.2	Changing server operation modes manually .....	62
4.4.3	BABYSITTER function (remote room listening in) .....	66
4.4.4	DO NOT DISTURB function .....	66
4.4.5	MCID – Malicious Call Identification .....	67
4.4.6	External devices control (I/O).....	68
4.4.7	Hotel features.....	69
<b>4.5.</b>	<b>Server programming using the telephone.....</b>	<b>70</b>
4.5.1	Access code for server programming using the telephone .....	70
4.5.2	Setting up the server IP address using the telephone.....	70
4.5.3	Announcement recording .....	71
4.5.4	Verification of announcements recorded by the user .....	72
4.5.5	Date and time setting .....	73
4.5.6	Deleting active bookings.....	74
4.5.7	Special service functions.....	74
<b>5.</b>	<b>Proprietary phones .....</b>	<b>75</b>
5.1	Digital proprietary phones.....	75
5.1.1	Messages on the digital proprietary phone display.....	80
5.1.2	Phonebook in digital proprietary phones.....	83
5.1.3	Programming buttons and LEDs in the digital proprietary phone .....	86
5.1.4	Direct Station Selection (DSS) console – key functions (Libra PBX Server only).....	87
5.1.5	Messages on the digital proprietary phone display.....	88
5.1.6	Programming buttons and LEDs using the telephone .....	90
<b>6.</b>	<b>Doorphones for the Proxima and Libra servers .....</b>	<b>93</b>
<b>7.</b>	<b>Voicemail.....</b>	<b>94</b>
7.1.	Using voicemail .....	94
7.1.1	Voicemail initiation .....	94
7.1.2	Forwarding calls to a voicemail inbox .....	94
7.1.3	Calling a voicemail inbox .....	95
7.1.4	Information about new messages .....	96
7.1.5	Direct access to a voicemail box.....	97
7.1.6	Voicemail connection (main menu level).....	98

7.1.7	Listening to voicemail messages.....	99
7.1.8	Listening to voicemail messages – profiles .....	101
7.1.9	Displaying date, time and caller's number.....	101
7.1.10	Returning calls .....	101
7.2	Voice-mail menu.....	102
7.2.1	MENU: While listening to messages .....	102
7.2.2	MENU: Personal settings.....	103
<b>8.</b>	<b>Acoustic signals.....</b>	<b>105</b>
<b>9.</b>	<b>User Zone .....</b>	<b>106</b>
9.1	User Zone – Configuration .....	107
9.2	User Zone – Call history .....	107
9.3	User Zone – Global phonebook .....	108
9.4	User Zone – Help .....	109
<b>10.</b>	<b>Short list of server functions .....</b>	<b>110</b>
<b>11.</b>	<b>Glossary.....</b>	<b>114</b>



**Note:** all functions described in the present manual concern **default settings** of the numbering plan. In the case of the numbering plan settings change, the current function dial numbers can be found online in the *User Zone* or obtained from the Proxima IP PBX Server or Libra PBX Server installer.

## 1. Introduction

We are pleased that you have chosen a telecommunications server offered by our company. The Proxima IP PBX Server, Proxima plus IP PBX Server and Libra PBX Server are the PLATAN's latest product line and are a state of the art IP telecommunications systems. They are characterised by their high quality, a wide range of functions and services, and easy operation. We hope you will be perfectly satisfied with your purchase and we are always willing to provide professional assistance and information about our products.

Proxima/Proxima plus IP PBX Server and Libra PBX Server's key features:

- Embedded VoIP – IP Gateway, IP EXT, **T.38** fax standard support
- Video calls
- ProximaWeb and LibraWeb – web-based server management
- Settings and call history accessible in User Zone via a web browser
- Advanced VoIP diagnostics
- Call recording ensuring security and higher quality of provided services
- See Who's Talking - video calls accessible to any number of users
- Proxima and Libra networking in Platan Intelligent Networking (PIN)
- Global phone book with up to 3 000 entries for proprietary phones
- Conference calls, **conference rooms**
- Intelligent Call Distribution (ICD) consisting in:
  - Interactive Voice Response (IVR) with multilevel call menu scenarios
  - Possibility of distributing calls to user groups according to the preset criteria: **queuing**, uniform (UCD), according to the topic selected via IVR, automatically – based on the recognised CLIP number (ACD)
  - 99 voice announcements (up to 30 h) for DISA and IVR
- Embedded Voicemail (25 channels)
- 4 melodies for waiting connections
- ARS/LCR – automatic least cost routing
- CLIP (Calling Line Identity Presentation) on all extensions
- Call registration and billing – 100 000 billing buffer
- Automatic fax signal recognition
- Controlling external devices – automatically or from mobile phone
- Hotel interface – support of hotel software
- Open PCTI protocol enabling the server integration with Call center, CRM systems and other applications and devices
- VEK (VoIP Cost Eliminator)

- Call Through (transit connection with automatic authorisation)

In order to operate the server properly, please read this manual carefully and keep it for future reference. The Proxima/Proxima plus IP PBX Server and LIBRA PBX Server manuals are organised as follows:

**Part 1** – Proxima or Libra server operation and maintenance manual covering the following issues:

- important features of the server;
- structure and installation procedure of the server.

**Part 2** – joint user manual covering the following issues:

- functions and services provided by the server, divided into incoming and outgoing calls;
- programming some server functions using the telephone;
- operating proprietary phones, consoles and door phones;
- built-in voicemail;

The majority of server functions are listed at the end of this manual in a shortened version.

**Part 3** – ProximaWeb/LibraWeb program operation manual covering the issues concerning the program operation and the server programming using a PC.

The server is accompanied with a hard copy of a Quick Start manual. User manual of Proxima/Proxima plus IP PBX Server and Libra PBX Server can be found on our website:

<http://www.platan.eu/offer/ip-pbx-telephone-systems/libra.html>

<http://www.platan.eu/offer/ip-pbx-telephone-systems/proxima.html>

<http://www.platan.eu/offer/ip-pbx-telephone-systems/proxima-plus.html>

**The server may be programmed by an authorised person only.**

We also invite you to visit our website [www.platan.eu](http://www.platan.eu), where information on new products and changes can be found.

## 1.1. Server programming

The server can be set up only by an authorised person using the **ProximaWeb**, **LibraWeb** or the **LibraPC** program.

Operation guidelines and the description of the server programming can be found in the *ProximaWeb* and *LibraWeb Program Operation Manual* provided as part of the server documentation.

Some of the server functions may be programmed using the telephone via a

dedicated **Programming mode**.

## 1.2. List of acoustic signals within the server

The following acoustic signals are possible when using the server:

- The server information tones that can be heard in the receiver when using the PROXIMA/LIBRA server are as follows:

- server dialling tone – a continuous tone heard after picking up the receiver, indicating that the server is ready to be used;



- second server dialling tone (a double beep before the continuous sound) – indicates that the call forwarding and the “do not disturb” functions are active;



- engaged tone – a periodic intermittent tone indicating that a line or a party that we are calling is engaged;




- “unavailable” tone – a periodic intermittent tone indicating that it is not possible to make a given call, e.g. because the granted privileges have been exceeded;




- confirmation (continuation) tone – a periodic intermittent tone indicating that the booking has been accepted;



- transfer mode tone – one of the melodies or announcements chosen by the user in the computer program;



- ring-back tone – a periodic intermittent tone in sync with the ringing tone rhythm heard by the party you are calling;



- Server call ringtones – phone ringing tones. The ringtone depends on the call type. Rhythms of ringtones are set up in the program (*menu: Common settings → Rhythms → Analogue phones*). Default (factory) ringtone settings are presented below:
  - Extension call ringtone – a periodic intermittent tone informing you about an incoming internal call:
    - 0.25 d / 0.25 p / 0.75 d / 3.75 p
  - External call ringtone – a periodic intermittent tone informing you about an incoming external call:
    - 1 d / 4 p
  - Alarm call ringtone – a periodic intermittent tone informing you about an alarm (or a wake-up call):
    - 0.25 d / 0.25 p
  - Group call ringtone – a periodic intermittent tone informing you about a Hunt Group call:
    - 0.5 d / 0.5 p
  - DISA call ringtone – a periodic intermittent tone informing you about an external call incoming in a DISA mode:
    - 0.75 d / 0.25 p / 0.25 d / 3.75 p
  - Doorphone call ringtone – a periodic intermittent tone informing you about an incoming call from a door phone:
    - 0.25 d / 0.25 p / 0.25 d / 0.25 p / 0.5 d  
/ 0.25 p / 0.5 d / 0.25 p
  - Voicemail call ringtone:
    - 0.25 d / 0.75 p

where   **0.25 d** – stands for 0.25-second ringtone

**0.5 p** – stands for 0.5-second pause



Different call ringtones can be defined in the program for proprietary phones.



DECT, ISDN and analogue phones with pre-installed tunes may not support the ringtones described above.

## 2. Access to the services offered by the server

A **function access symbol** has been introduced in the server. This symbol should be pressed before the combination of digits responsible for a specific server function. After the function access symbol has been entered, the numeration range is expanded and the conflict between the server function codes and its numeration plan is solved. The user may choose between using a function access symbol and working in a standard service access mode. The function access symbol is set by default to “\*.”

### Types of access to functions:

- standard – access to the server functions is gained by entering the combination of digits to which certain functions are assigned;
- after entering # – # must be entered before the combination of digits;
- after entering \* – \* must be entered before the combination;

The above settings do not apply to the functions carried out after pressing the **Flash** button, such as for example: **transferring internal and incoming external calls, hold** function, etc. Dialling emergency, extension and external numbers (with the “0” prefix) requires no special symbol as well.

The type of access to the server functions from the phone is defined in the program (*menu: Common settings → Global settings*).



Conferences require a special symbol to be used after pressing the **FLASH** button, e.g. Flash \*7 “TEL.”



The symbol for exiting the **Hotline** function is defined in the computer program (*menu: Common settings → Global settings*). If the symbol for exiting the **Hotline** function is the same as the access symbol to the server functions, the exiting symbol must be entered twice in order for the function to work.

## 3. Making calls

### 3.1. Internal calls

Internal calls are calls between the extensions (users) connected to the Proxima / Libra server. Users are assigned (*by means of the computer program*) to Hunt Groups (max. 16 groups). It is also defined to which Hunt Groups they may make internal calls (*menu Extensions → Traffic classes*, assigned in extension privileges). Calls to the door phone are also internal calls. Regardless of the above, extensions may be assigned to Hunt Groups.

#### 3.1.1 How to make an internal call



Pick up the phone.

You will hear a dialling [tone](#).



Dial an extension or a Hunt Group number.

The extension numbers range is set by the installer. The numbers may consist of 1-16 digits.

When the access to the server functions is set without any special signs (\* or #), function access codes and emergency numbers should be excluded from the numbering plan.

A ring-back tone means that a connection will be established after the called party answers.

If you hear an engaged tone, try again after a while or book a call ([Booking a call to an engaged extension](#)).

An offering tone (in the form of quiet beeping) heard (in the background) during a call means that an external call (or a Hunt Group call) is waiting to be answered. After the conversation has ended and the phone has been hung up or after the call has been put on hold (HOLD) and the phone has been hung up, a ringing tone will be heard, indicating that the server is putting you through to the waiting extension user.

### 3.2. External calls

External calls – calls between extension users (server users) and outside parties.

Outgoing calls may be made by authorised users only (privileges of each server user are granted by the server installer or by the service technician in the [computer program](#)).

The basic method of accessing trunk lines is to press **0**. Using the [computer program](#), the installer determines the trunk lines which will be available to a given user after pressing 0. In addition, the installer may make the following trunk lines available: \*81, \*82, \*83, \*84 and \*80a\*b\*c#, where: a – unit number, b – slot number, c – port number on the server card, while \* is a function [access symbol](#).



If you want to make an external call:

Pick up the phone.

You will hear a dialling tone.



Dial



You will hear:

- local exchange (LE) dialling tone
- engaged tone if the trunk lines connected to the server are engaged
- “unavailable” tone if your phone is not privileged to make outgoing calls or if its trunk line is blocked with an individual code.



Dial an external number.

You will hear a ring-back tone from the local exchange. The tone type depends on the status of the outside party – idle, engaged or unavailable.

If an external number is engaged, a call to this external number may be booked (Booking of a call to an external number – functions: \*92, \*94, \*95).

It is not possible to programme direct access to a trunk line using the telephone (i.e. without dialling “0”), but it is possible to do so from the computer program level – the so-called *Hotline*.



Hotline is not available from VoIP phones.

### 3.3. Video calls

Video calls – these are calls made within the Proxima IP PBX Server or Libra PBX Server with the use of VoIP technology. The video calls are available for:

- Libra users equipped with Platan Video Softphone app. with audio/video accessories
- Yealink VP-530 IP video phones users
- Helios IP video door phones users.

Video calls may be made as internal (extension-to-extension) calls between users equipped with the above mentioned devices or between an internal user and an external user equipped with IP video phone or Platan Video Softphone app., when the call is made through a VoIP trunk line with a video calls support enabled.



Video call is made bypass media, meaning that the video stream is sent outside the Proxima / Libra server. Possibility of making a call and its quality depends on the used devices, LAN/WAN network quality and bitrate. Single video call requires the bitrate from 64kb/s up to 4Mb/s in both directions (download/upload).

#### 3.3.1 Internal video calls



Dial an extension number or a Hunt Group number. The extension numbers range is set by the installer. The numbers may consist of 1-16 digits.



Select *Video* option on an IP video phone or in Platan Video Softphone app. and pick up the video phone receiver (or press the green receiver + camera button in the Platan Video Softphone app.).

#### 3.3.2 External video calls

Outgoing video calls can be made only by privileged users (privileges for every server user are given by the installer or by the server maintenance personnel in the computer program).

The main access to the trunk lines (escape code) is achieved by dialling '0'. Installer defines in the computer programme which trunk lines will be available for users after dialling '0'. Additionally, the following dial numbers can be allowed by

the installer to access trunk lines through different trunk lines bunches: \*81, \*82, \*83, \*84 and \*80a\*b\*c#, where: a – unit number, b – slot number, c – server card port number, and \* - [function access symbol](#).

If you want to make an external video call:

 Dial  and then dial the external number.



Select *Video* option on an IP video phone or in Platan Video Softphone app. and pick up the video phone receiver (or press the green receiver + camera button in the Platan Video Softphone app.).

## 4. Services offered by the server

### 4.1. Services connected with incoming calls

#### 4.1.1 Analogue trunk lines

The server may operate in three different modes of handling incoming calls from analogue trunk lines (CO). The installer must properly set up the modes described below as call schemes using the [computer program](#).

#### None MODE (no message)

A server operating in the **None** mode establishes an incoming call from a trunk line with the defined Hunt Group (from 1 to 16 extensions).

If an outside party is calling a user of the server working in the **None** mode, the procedure is as follows:



- A server external number is dialled.
- A server ring-back tone is heard (idle or engaged).



- The server establishes a call with the extensions defined for this mode.

#### Announcement MODE

In the **Announcement** mode, the server plays the welcome voice message or the tune while establishing a call with the defined Hunt Group.

If an outside party is calling a server user working in the **Announcement** mode, the procedure is as follows:



- A server external number is dialled.
- A tune or a welcome message is heard,  
e.g. "This is .... Please wait for the operator to answer..."



- While playing the tune, the server establishes a call with extensions in the order determined in the Hunt Group.

## MODES: DISA and IVR

In the [DISA](#) mode (Direct Inward System Access), having dialled the number, an external caller hears an announcement in the course of which they can tone-dial the server extension number. The time devoted to dial an extension number is definite and set in the computer [program](#) (*for* in *Call schemes*). The IVR (Interactive Voice Response) mode is an extended DISA mode.

In order to use the DISA or IVR function, an outside caller must use a phone with tone dialling ([DTMF](#)).

If an outside party is calling a server extension working in the DISA mode, the procedure is as follows:



A server external number is dialled.



A welcome announcement is heard,  
e.g. "This is .... Please tone-dial the extension number"



An extension number or a different number (as stated in the announcement) is dialled.



The server establishes a call with the selected extension or Hunt Group.

After the DISA time has lapsed and the outside party has not dialled any extension number, the server follows the scenario defined in the computer [program](#).

### **4.1.2 Call queuing**

Call queuing makes it possible to handle the calls directed to the Hunt Groups, which, due to the Hunt Group members being busy with other ongoing calls, cannot be answered at once.

Call queuing makes it possible to handle up to 40 excessive calls directed to the Hunt Group through a call scheme. Queued callers may hear the information about their position in queue and estimated waiting time.

Additionally, the selected numbers may be tagged as VIP, thus having a priority in queue when Hunt Group members are busy.

Queue and VIP settings are made in Proxima/Libra computer programme.

### 4.1.3 ISDN trunk lines

#### MODES: None, Announcement, DISA, IVR

The server working in those modes supports digital trunk lines in a manner similar to that employed in the case of analogue trunk lines. The digital ISDN BRA trunk line may handle two calls at the same time (this is due to the distribution of ISDN-BRA access into two B channels, both of which may be separately used as a traffic channel). By the same token, the ISDN-PRA (30B+D) line may handle up to 30 calls at the same time.

#### **Using the DDI (Direct Dial-In) service:**

The server makes direct dialling of the extension number possible for the outside party. In order to use this function, the following conditions must be met:

- the server is connected with the telecom operator via the ISDN line;
- the user has a group of DDI numbers assigned by the local telecommunications operator;

Using the computer program, the server installer should programme the server to handle DDI numbers (*menu: Call distribution → MSN/DDI incoming calls*).

If an outside party wishes to call a server user using the DDI function, the procedure is as follows:



Dial the DDI external number of an extension, e.g. 585558888.

- The outside party will hear a ring-back tone – if the selected extension is idle (it may also be engaged – in such a case, the extension user hears a tone offering an external call in the background).
- The outside party will hear an engaged tone – if the selected extension is engaged and it has the “*no waiting call indication*” function on.
- The outside party will hear an "unavailable" tone – if the DDI traffic setup within the server is incorrect or if there is no such number.

### 4.1.4 Automatic Call Distribution – ACD

The server offers the **ACD** (*Automatic Call Distribution*) function based on the identified CLIP (*Calling Line Identification Presentation*) number. Using this function, the server will route incoming calls, e.g. to selected extension users, based on the **ACD tables**.

Full configuration of the **ACD tables** is carried out in the computer program

(menu: *Call distribution → ACD tables*).

The **ACD tables** may contain the following data:

- Full external number and information on the handling method, i.e. whether it should be routed to a specific extension or to a **Hunt Group**, or whether it should be handled in accordance with the pattern defined for a selected trunk line.
- Initial part of an external number (**Prefix**) – in such a case, external numbers (within the incoming traffic) starting with the defined prefix will be distributed by the server as specified in the **ACD table**.

Using the **Automatic Call Distribution** from analogue trunk lines (CO) requires **CLIP** phones to be used and the **CLIP** function to be offered by the telecommunications operator.

More information can be found in the *Part 3. ProximaWeb / LibraWeb program operation manual*.

#### **4.1.5 Call transferring**

During a call – if a caller wishes to talk to another person, the call may be transferred without being ended.

If you wish to transfer a call to another extension:

##### **TRANSFERRING WITH OFFERING**



Do not hang up the phone! Press



You will hear a continuation tone.



Dial the number of the user to whom you want to transfer the call. This can be either an extension or an external number. The caller hears a tune, an announcement or a ring-back tone (depending on the [Analogue trunk lines](#) configuration), or a tone set in the computer program (*Common settings → Calls → Internal calls*).



Wait for the called party to answer and provide them with the information about the call.



Hang up the phone.

The offered call has been taken over by another person.

## TRANSFERRING WITHOUT OFFERING



Hang up the phone before the called party to whom the call is transferred answers. The extension user will gain access to the transferred external call after picking up the phone. If the extension user fails to answer, the transferred call will return after the time set in the computer program *Common settings* → *Ring tone and server times* → *Ringtone times* → *Ringtone time to Ext. B* (default setting: 60 seconds).



If the user to whom the call is transferred is engaged, the transferring person may resume the call at any time (provided that they have not hung up the phone) by pressing



The **FLASH 0** sequence allows resuming the call after about two seconds provided that no other digit is dialled within that time. Dialling any other digits will be interpreted by the server as transferring the call to an external number.



A user may transfer calls to an external number under the condition that proper privileges have been set using the computer program (*Extensions* → *Service classes*). (☞)

### 4.1.6 *Return calls (consultations)*

During a telephone conversation with an outside party, you may contact another internal user (a colleague) without ending the external call.



You are having a telephone conversation with an outside party.

If you wish to contact an internal user at the same time:



Do not hang up the phone!!! Press **FLASH** or short press the cradle.



Dial the extension number.



You will hear [a ring-back tone](#).

Wait for the user to answer.



The outside party is waiting for your call to end.

They are hearing a melody, an announcement or [a ring-back tone](#) (depending on the server settings).



The internal user has answered. You hold a telephone conversation.



After the conversation with an internal user has ended and they have hung up the phone, a connection with the waiting outside party is established again.



You may resume the external call on hold at any time by pressing



#### **4.1.7 Offering an external call to an engaged user**

If in the course of [transferring](#) an external call to an internal user you conclude that they are having another telephone conversation, you may intrude as the third interlocutor and offer them the waiting call (the user to whom the call is to be transferred must have the *call intrusion authorisation* function on and the *no waiting call indication* function off, while the user transferring the call must have the *call offering to engaged extension, transferring internal calls and transferring incoming calls* functions on). This function is unavailable during a conference.

If you wish to transfer an external call to another internal user:



Press FLASH.

Dial the extension number.



When you hear an [engaged tone](#), dial  in order to offer the external call.




You will be included in the ongoing conversation.

Inform the engaged user about the waiting call – the information will be heard by both the user and their interlocutor.



When you obtain the information that the waiting call can be transferred:

Resume the call on hold by pressing



Transfer the waiting call to the engaged user by using the function of **Transferring an external call to an engaged extension user** or – if the user cannot interrupt the ongoing call – [transfer](#) the call to another user.



Hang up the phone.

#### 4.1.8 Transferring an external call to an engaged user

If in the course of [transferring](#) an external call to an internal user you conclude that they are engaged, you may set the external call to the waiting call mode. As a result, the server will inform the user about the waiting external call by an alarm [tone](#) heard in the background.

If you wish to transfer an external call to an user having another telephone conversation and if the outside party is willing to wait:



Press **FLASH**.



Dial the extension number.



After hearing an [engaged tone](#), hang up the phone.



The external caller waits for the conversation held by the extension user to end. The user having a telephone conversation will hear an alarm tone informing them about the waiting call (*cyclical, quiet beeping*).



After the conversation held by the internal user has ended and they have hung up the phone, the server will put them through to the waiting outside party.

The period of time the server waits for the call to end is set in the computer [program](#) (*Common settings → Ringtone and server times → Ringtone times*). If the waiting time has exceeded the predetermined limit and no connection has been initiated, the external call will return to the transferring user.

#### 4.1.9 HOLD – external call hold

If you are having a telephone conversation with an outside party, you may put this call on hold for a moment (for example in order to answer a call from another trunk line or to [consult](#) with another user) and then return to the call on hold and resume the conversation.

If in the course of a conversation held with an outside party you wish to put the call on hold for a moment:



Press **FLASH** or short press the cradle.



You will hear a continuation [tone](#).



Dial YOUR extension number – “TEL.”



Hang up the phone.



The call has been put on hold for a specific period of time set in the computer program (*60 s by default*).

(see menu: *Common settings* → *Ringtone and server times* → *Ringtone times*).

The party put on hold will hear a melody or an announcement.



The call put on hold may be resumed before the time limit has expired by picking up the phone and dialling your extension **TEL** number.

If the call is not resumed within the predetermined time, the server will automatically put it off hold by calling the user who has used this function with a trunk line ringing tone.

Announcements or melodies for the **HOLD** function are defined in the computer [program](#): for external calls (see *Call distribution* → *Call schemes* → *While transferring*) and for internal calls (see: *Common settings* → *Calls* → *While transferring*).

The **HOLD** function allows the user to put on hold only one phone call held at a given moment with an outside party.

#### 4.1.10 Transferring a call to another trunk line

If you are having a telephone conversation with an outside party, you may transfer the call to another outside party, e.g. to the mobile phone of an employee staying outside the company's premises. The user transferring a call must be authorised in the computer program to **transfer internal calls** and to **transfer calls to outside parties** (*menu: Extensions → Service classes*).

If you are having a telephone conversation with an outside party and you wish to transfer the call to another outside party (at the expense of your server):

 Press **FLASH**.  
You will hear a [continuation tone](#).

 Select another trunk line, e.g. **0**, and dial the number of an outside party to whom you want to transfer the external call put on hold.

The lines are connected for the time predetermined in the computer [program](#) (*Common settings → Calls*).

The interlocutors may **prolong** the declared call duration. Having heard an alarm tone (*three short tones*) indicating that the time is running out, one of them must press (\*). Otherwise, the connection will be broken 10 seconds after the tone.

#### 4.1.11 Return external call

Unblocking this function may allow third persons (*knowing the function access code*) to make external calls at the expense of the server's owner. In order to prevent any instances of abuse, frequent changing of the access code ([access number](#)) or activation of the individual mode described below is recommended.

This function may be activated either in the global (*for all users knowing the access number and the password*) or the individual mode (*additionally, the user must provide their extension number and their individual server password, and must be authorised to use the access number*). The mode is activated in the computer [program](#) (*menu: (Common settings → Calls)*).

 This function is active only in the [DISA or IVR mode](#) for trunk line handling.

If you want to make a call, e.g. from your home to a long-distance number, you may use this function and call your server and, having entered the [access number](#) (*or numbers*), connect (*at the expense of the server*) with an outside party to hold a telephone conversation. You will only have to pay for the connection with the server.



Pick up the phone.



Dial your server external number.

Having heard the message ([DISA or IVR mode](#)), dial the [access number](#).

You will hear a confirmation [tone](#).



Enter the **password** (*access code with the length of up to 8 digits*) defined in the computer program along with the [access number](#).

Optionally, (*in an individual mode of this function*) it is necessary to enter your own extension number and an individual password (*up to 6 digits*) assigned in the computer [program](#) (*menu: Extensions → Phone blocking*). Such a call is then attributed to a specific user (*own extension number*).

Having entered the above-mentioned codes, you will hear: a trunk line dialling [tone](#) – if the function is available for you, engaged [tone](#) – if the function is available but all trunk lines in a trunk line bunch (*assigned to this function*) are engaged or “unavailable” [tone](#) – if you have no access to this function.



Dial the outside party's number (*provided that you have gained access to the trunk line*).

The connection will be established for the time determined in the computer program.

Activation of this function, determination of the **access number**, **password** (*including switching on an individual mode*) and declaration of the **call duration** is made in the computer [program](#) (*menu: Common settings → Calls*).

The server registers calls also in the case of the described return external call. The calls are ascribed to the account of the **User 9999** (*in the case of the global mode*) or to individual users' accounts (*in the case of the individual mode*). It is possible to check which trunk line was used for the call, what the dialled number was and what the call duration was.

#### **4.1.12 Call Through**

Call Through is an external return call (transit call) with automatic authorisation. It permits to make calls from authorised numbers (e.g. mobile phones) on the server's expenses.

First, the external numbers authorised to make Call Through should be defined in the computer program. The authorised user, after having connected to the Proxima or Libra server and after having heard the voice announcement, dials the escape code ('0' or any other digit or code defined by the installer) to reach the trunk line, and then dials an external number to call. After a correct automatic authorisation the server will establish an external return call.

Call Through calls will be registered in the Penny billing module under number 9994.

#### **4.1.13 Capturing and returning calls**

You hear your colleague's phone ringing or an incoming call is signalled on the proprietary phone or on the console. If you wish to capture this call:



Pick up the phone.



Dial **\*** **7** **1** **TEL**,

where TEL stands for the number of the extension user whose call you are capturing.



You have captured a call directed to another user.



In the manner described above, you may either capture external calls or internal calls provided that you have been granted the necessary privilege and that you know the number of the called phone.

The server makes it possible to capture a call directly from the proprietary phone and console speed dialling buttons. However, it is required that the called number be defined **under the speed dialling** button.

## RETURNING CALLS

If an internal, extension-to-extension call, has not been answered, you may call back this extension number (calling you recently):

 Dial **\* 7 1 TEL**,  
where TEL is YOUR extension number.

### 4.1.14 Capturing external calls

You hear your colleague's phone ringing. If you do not know the number of this phone and the ringing tone informs you that this is an external call, you may capture it:

 Pick up the phone.

 Dial **\* 7 1 0**

 You have captured an external call directed to another extension user.



If two trunk lines are calling at the same time, you may – by using this function – capture the call from the trunk line which called first.  
In order to use this function, you must be granted the necessary privilege in the computer program.



If the *Hunt Group capturing* privilege is assigned in *Extensions → Traffic classes*, you may – by using this function – capture an external call directed to the Hunt Group.

### 4.1.15 Unconditional call forwarding to another telephone - CFU (I'm there)

This function makes it possible to forward any call directed to your phone to the phone of another extension or outside party, or to a voicemail number (*if it is active*).

In order to use this function:



Pick up the phone.



Dial  TEL

You will hear a confirmation [tone](#),

where TEL stands for the number of the phone to which calls directed to your phone are to be forwarded. External number should be preceded with 0, e.g. 0585558800.

If you wish to cancel the unconditional call forwarding function:



Pick up the phone.



Dial 

You will hear a confirmation [tone](#).



Hang up the phone.



If the function of forwarding calls to an external number is used, each call is rated as a regular outgoing external call.

#### ***4.1.16 Unconditional call forwarding to a selected extension – CFU (I'm here)***

This function makes it possible to forward any call directed to your extension number to a selected (*from the place you are staying in*) telephone (*call here*). In this manner, by “logging into” the server, you define the place to which it should direct all calls.

If you want the calls directed to your extension number to be forwarded to the selected telephone:



Pick up the phone to which you want the calls to be forwarded.



Dial **\* 7 3 5 TEL**

You will hear a confirmation [tone](#), where TEL – your phone number.



Hang up the phone.

The server will forward all your calls to the telephone from which you have sent the command.

#### If you want to cancel the call forwarding:



Pick up the phone.



Dial **\* 7 3 4**

You will hear a confirmation [tone](#).



Hang up the phone.

The server will cancel all unconditional call forwardings concerning your telephone.

#### **4.1.17 Call forwarding when my number is busy (CFB)**

This function makes it possible to forward any call directed to your telephone to a selected number when your extension number is engaged.

#### If you want the calls directed to your extension number to be forwarded to the telephone number you select when your extension number is busy:



Pick up the phone.



Dial **\* 7 3 6 TEL**

You will hear a confirmation [tone](#),

where TEL stands for the telephone number to which you forward calls.

The external number must be preceded with 0, e.g. 0585558800.



Hang up the phone. When you are engaged, the server will forward your calls to the telephone number you have selected (e.g. an extension, an external or a voicemail number).

If you want to cancel the **when busy** call forwarding:



Pick up the phone.



Dial

You will hear a confirmation [tone](#).



Hang up the phone.

The server will cancel the “when busy” call forward concerning your telephone.



If the function of forwarding calls to an external number is used, each call is rated as a regular outgoing external call.

When you call a Hunt Group to which the user with an active function of forwarding calls to an external number “when busy” belongs, this user will hear an offering tone, while other users within the Hunt Group will be called.

#### **4.1.18 Call forwarding when my telephone fails to answer (CFNA)**

This function makes it possible to forward any call directed to your telephone to a selected number when your telephone fails to answer.

If you want the calls directed to your extension number to be forwarded to the telephone you select if they fail to be answered within 20 s:



Pick up the phone.



Dial TEL

You will hear a confirmation [tone](#),

TEL stands for the telephone number to which you forward calls.  
The external number must be preceded with 0, e.g. 0585558800.




Hang up the phone.

If a call directed to your telephone fails to be answered within 20 s, the server will direct such a call to the number you have selected (e.g. an extension, an external or a voicemail number).

If you want the calls directed to your extension number to be forwarded to the telephone you select if they fail to be answered within tt time:



Pick up the phone.



Dial  TEL  tt,

You will hear a confirmation [tone](#),

TEL stands for the telephone number to which you forward calls;  
tt – time [s] after which the forward is to be carried out.



Hang up the phone.

When the call directed to your telephone fails to be answered for tt seconds, the server will forward the call to the number you have selected.

The tt time may be between 5 s and 80 s (5 s interval). The server rounds up the entered time, i.e. if the value of 31 s is selected, the server will forward calls after 35 s. If you want the forwarding to be activated after 5 seconds, enter 05.

If you want to cancel the “when no answer” call forwarding:



Pick up the phone.



Dial 

You will hear a confirmation [tone](#).



Hang up the phone.

The server will cancel the “when no answer” call forwarding.

If the function of forwarding calls to an external number is used, each call is rated as a regular outgoing external call.

All functions connected with forwarding calls to either your or another telephone may also be defined, modified and cancelled in the computer [program](#) (*menu: Extensions → Call forwarding*).

#### **4.1.19 Call forwarding when my VoIP phone is not reachable (CFNR)**

This function makes it possible to forward any call directed to your VoIP telephone to a selected number when your telephone is not reachable.

The function is executed when:

- the VoIP extension is logged out
- 100/Proceeding answer
- no answer (eg. phone disconnected).

If you want the calls directed to your VoIP phone to be forwarded to the telephone you select if they fail to be answered within 20 s:



Pick up the phone.



Dial \* 7 3 8 TEL,

You will hear a confirmation [tone](#).

TEL stands for the telephone number to which you forward calls;  
The external number must be preceded with 0, e.g. 0585558800.



Hang up the phone.

If a call directed to your VoIP phone fails to be answered within 20 s, the server will direct such a call to the number you have selected (e.g. an extension, an external or a voicemail number).

If you want the calls directed to your VoIP phone to be forwarded to the telephone you select if they fail to be answered within tt time:



Pick up the phone.



Dial \* 7 3 8 TEL # tt,

You will hear a confirmation [tone](#),

TEL stands for the telephone number to which you forward calls;  
tt – time [s] after which the forward is to be carried out.



Hang up the phone.

When the call directed to your VoIP telephone fails to be answered for tt seconds, the server will forward the call to the number you have selected.

The **tt** time may be between 5 s and 80 s (5 s interval). The server rounds up the entered time, i.e. if the value of 31 s is selected, the server will forward calls after 35 s. If you want the forwarding to be activated after 5 seconds, enter 05.

If you want to cancel the “when not reachable” call forwarding:



Pick up the phone.



Dial **\*** **7** **3** **8**

You will hear a confirmation tone.



Hang up the phone.

The server will cancel the “when not reachable” call forwarding

If the function of forwarding calls to an external number is used, each call is rated as a regular outgoing external call.

All functions connected with forwarding calls to either your or another telephone may also be defined, modified and cancelled in the computer program (*menu: Extensions → Call forwarding*).

#### ***4.1.20 Logging into and out of the Hunt Group***

The server makes it possible to log out an extension user from a given Hunt Group (see: Group call). When a user leaves their workstation, they may use this function to prevent the server from directing incoming calls to them.

In order to log out of the Hunt Group:



Pick up the phone.



Dial **\*** **7** **3** **0** **XXX** **0**,

where **XXX** stands for the number of a given Hunt Group.



Hang up the phone.

You have been logged out of the Hunt Group. The server will no longer direct this

Group calls to you.

If a server user has logged out when leaving their workstation, they may log into the Hunt Group again on coming to work and the server will start directing incoming calls to them again.

In order to log into the Hunt Group:



Pick up the phone.



Dial **\* 7 3 0 XXX 1**,  
where **XXX** stands for the number of a given Hunt Group.



Hang up the phone.

You have been logged into the Hunt Group. From this moment on, the server will direct Group calls to you.

In order to log out of all Hunt Groups:



Pick up the phone.



Dial **\* 7 3 0 0 0**



Hang up the phone.



The fact of logging into and out of a Hunt Group is recorded in the server operation report.

The number of the Hunt Group to which you belong should be provided by the installer or by the server maintenance personnel.

## 4.2. Services connected with outgoing calls

Using the computer program, it is possible to grant users individual privileges concerning the majority of functions related to outgoing calls (e.g. to restrict the access to trunk lines for outgoing calls). These functions are described later on in this *manual*.

### 4.2.1 Limiting the duration of external calls

The server offers the possibility of determining the duration of outgoing external calls (from 60 s to 900 s) for every extension user. To activate this function and to determine the duration of an outgoing external call, the computer [program](#) must be used.

### 4.2.2 Direct access to emergency telephone numbers

If you want to call the Police, the Emergency Service or the Fire Service, you may do it using any telephone connected to the server (including the telephones that are blocked and/or with no access to trunk lines) without the need to select the trunk group, e.g. “0.” If the LCR function is used within the server, emergency telephone numbers should be configured in the [LCR table](#) in such a way as to use the services of a specific telecommunications operator.

If you have to use this function:



Pick up the phone.

You will hear an IP dialling [tone](#).

Dial:

• **Universal emergency telephone number**

• **Police**

• **Fire Service**

• **Emergency Service**

1	1	2
9	9	7
9	9	8

9	9	9
---	---	---

### 4.2.3 External calls through selected trunk lines

The server can define a number of access routes to trunk lines in outgoing traffic for each user.

- Access to the lines: **0**      trunk lines available after dialling “0”;

- Access to the lines: \***81**
- Access to the lines: \***82**
- Access to the lines: \***83**
- Access to the lines: \***84**
- Access to the lines: \***80a\*b\*c#**

trunk lines after dialling \*96 – with the CLIR  
 trunk lines available after dialling “\*81”;  
 trunk lines available after dialling “\*82”;  
 trunk lines available after dialling “\*83”;  
 trunk lines available after dialling “\*84”;  
 trunk lines available after dialling “\*80a\*b\*c#”,  
 where a – unit number, b – slot number,  
 c – card port number (selection of a specific  
 trunk line);

Trunk lines within the PBX server are grouped into **trunk lines bunches**. The server makes it possible to define 16 trunk lines bunches using the computer [program](#). For each of the above-mentioned access routes, a **trunk lines bunch (01-15)** or **access denied** is assigned. Thus, it is determined which access routes a user should use and, as a result, through which trunk lines (*included in the assigned trunk line bunch*) they may make calls.

Various access routes to trunk lines are important when trunk lines of different telecommunications operators, GSM and VoIP gateways are connected to the server. A user may then “manually” select a specific trunk lines bunch to make an external call (\*81, \*82, \*83, \*84), e.g. to call mobile operators via the GSM gateway.

The server may handle automatic external calls taking into consideration the lowest cost of the established connection ([LCR](#) service). Thanks to this function, the server may automatically (according to the **LCR table** settings) select the trunk line (operator) to establish a connection.

**80xxx** access to the line makes it possible to select a specific trunk line. The trunk line may be selected by dialling \*80a\*b\*c#, where:

a – unit number,  
 b – slot number,  
 c – card port number,

e.g. \*803\*12\*4# – trunk line in the third unit, 12th slot on the 4th card port.

#### 4.2.4 Outgoing external calls with **CLIR**

The server allows outgoing external calls with the presentation of your own external number manually and intentionally deactivated – [CLIR](#) function.

Privileges to use trunk lines are analogous to those applied in the case of outgoing

external calls after dialling “0.”

In order to block the calling line identification presentation during an external call:



#### **4.2.5 Least Cost Routing – LCR service**

**LCR service** (*Least Cost Routing*) consists in an automatic analysis of the number dialled by the user in order to route the call through trunk lines ensuring the cheapest connection (e.g. depending on the time of the day). This service may result in changing the first part of the number (prefix) or in changing the whole number to another, determined in the **LCR tables**. Next, the right trunk line bunch is selected, through which the call will be made (provided that the user is authorised to use this trunk line bunch). Efficiency of the LCR service depends on the **LCR tables'** settings and configuration of users' privileges granted by the installer.



LCR is employed in processes between the server and the local exchange with the use of any trunk lines bunch only after a proper configuration in the computer program.

The **LCR tables** are analysed after each digit dialled by the user. The process is concluded (the **trunk lines bunch** is assigned) when it is known that dialling of any other digit will not change the selected prefix. The time for selection of the trunk lines bunch is limited (the so-called timeout), i.e. after a specific period of time for dialling of the number by the user, the calling party will hear an “unavailable” tone.

If the **LCR tables** contain no “empty” prefix and the number dialled by the user has not been found, the server functions as if the LCR service was switched off for this user.

Using the computer program (*Extensions → Traffic classes*), the **trunk lines bunch** (01-32) containing all trunk lines used in the **LCR tables** should be assigned to the user in the **Line access** field. A restriction on trunk lines within this trunk lines bunch will make the missing lines inaccessible for a given user and the server will not make calls through such lines. Such a situation may be intentionally used to restrict outgoing calls (e.g. to mobile operators).

The server allows defining **alternative** server and bunch **prefixes**, through which

the call is to be made if the “first route” is engaged or damaged.

The LCR service is configured in the computer [program](#) (*Call distribution → LCR tables*).

#### **4.2.6 Booking a trunk line call**

If you wish to connect with a trunk line and you hear an engaged tone after dialling e.g. “0,” you may book a trunk line call. Thanks to this option, you will not have to dial “0” repeatedly to check if the trunk line is idle.

If you want to book the trunk line:



Pick up the phone.

You will hear a dialling tone.



Dial the number of a trunk line bunch, e.g. **0**, in order to connect with the local exchange.



If you hear an engaged tone, press **0**.

You will hear 2 short tones confirming the booking acceptance.



Hang up the phone.

If the trunk line becomes available, your phone will ring with a calling tone. You will gain access to the trunk line after picking up the phone, without the need to dial the trunk lines bunch number (in this case – **0**).

You may also book a specific trunk line. Then, when you hear an engaged tone after dialling **80a\*b\*c#**, you book the line by pressing **0**.

When the [LCR service](#) is active and trunk lines are engaged, you will not hear the trunk line engaged tone right after dialling “0.” This is conditioned by the LCR functioning method. The engaged tone will not be heard earlier than in the course or after dialling the external number. Therefore, a connection with the trunk line will be booked after “0” is pressed while the engaged tone is heard.

#### 4.2.7 Booking a call to an engaged extension

If you wish to call an extension and you hear an engaged tone, you may book a connection with this extension. Thanks to this option, you will not have to dial the number repeatedly to check if the extension is idle.

If you wish to book a connection with an engaged extension:



Pick up the phone.

You will hear a dialling [tone](#).



Dial the **extension number**.



If you hear an engaged [tone](#), press



You will hear a confirmation tone.



Hang up the phone.

When the booked user ends their call and hangs up the phone, the server will ring with a calling tone and will call the booked user when you pick up the phone.

#### 4.2.8 Call booking through a secretary

The server administrator should, using the computer program, grant the secretary the following privileges:

- transferring internal, incoming and outgoing calls,
- call offering possibility,
- call intrusion authorisation,
- putting calls on hold (HOLD),
- establishing calls (functions: \*9x),
- booking access to the external line.

The **Secretary** user may accept the order to establish a connection with an outside party and to transfer this call to an extension user. However, the secretary must be authorised by the administrator to perform the above-mentioned tasks.

If you want the intermediate user (**secretary**) to establish a connection for you:



Pick up the phone.



Call the secretary.

Ask for establishing a connection with the selected outside party by providing them telephone number and your extension number.

Having established a connection with the selected outside party, the secretary will inform them about the call and then will forward this call to you (see: [Call transferring](#)).

If you are having a telephone conversation with another user at that moment, the secretary may join in the conversation with the alarm tone heard in the background (if a specific privilege has been granted).

Most often, the secretary is considered to be a user equipped with a proprietary phone. However, any extension user having “secretary” privileges may perform the function of a secretary.

#### **4.2.9 Group call – Hunt Groups**

If you wish to call any of the extension users responsible for the same tasks (e.g. one of many trade department employees), you may use a group call function. The server allows defining up to **32 Hunt Groups**, i.e. groups called by dialling the same extension number. Each Group may be composed of up to 16 server users.

If you want to use the **group call** function:



Pick up the phone.



Dial a **Hunt Group** dialling number.

A **Hunt Group** user to pick up the phone first will speak with the caller. If a Hunt Group user has the voicemail forwarding on, the forwarding is not carried out if this Hunt Group is called.

In addition, the server allows you to:

- forward calls to Hunt Groups,

- dial the Hunt Group dialling number in the [DISA](#) mode,
- assign a [DDI](#) number to a Hunt Group.

The **Hunt Group** dialling number cannot be the same as any other number within the server e.g. extension users' numbers.

A **Hunt Group** dialling number differs from its ordinal number. One must ensure, especially when using the [Logging into and out of a Hunt Group](#), that the dialling number is not confused with the ordinal number.

#### **4.2.10 Calling onto the proprietary phone speaker**

The server makes it possible to send messages directly onto the proprietary phone speaker. In order for a user to use this function, they must be granted the **speakerphone call** privilege in the computer [program](#) (*menu: Extensions → Service classes*).

If you want to make a call directly onto the proprietary phone speaker phone:



Pick up the phone.



Dial **\* 7 9 TEL**,  
where TEL – proprietary phone number.



After one call tone, a speaker circuit will switch on in the proprietary phone and it will be possible to communicate the message.



Calling onto the proprietary phone speaker is possible only for one telephone at the same time.

#### **4.2.11 Redialling the last dialled external number**

If you want the server to redial the most recently dialled number of an outside party, such a service is available. You do not have to dial the same number repeatedly if it is engaged. What you need to do is to use the function described below after picking up the phone.

If you want to redial the last dialled external number:



Pick up the phone.

You will hear a dialling tone.



**Do not hang up the phone!!!**

You will hear a routing [tone](#) – the server will be trying to establish a connection with the external number you have dialled most recently. If the number is engaged again, hang up the phone and try again after a while or use the [\\*92](#), [\\*94](#) functions described further.

#### **4.2.12 Booking a call to the last dialled external number**

If the outside party you are calling is engaged, you may order the server to make this call. Thanks to this option, you will not have to dial the same external number repeatedly to check if it is available. When the call is made, the phone will ring with a calling ringtone.

If you wish to make a call to the most recently dialled external number:



Pick up the phone.

You will hear a dialling tone.



Dial the trunk line **access number**, e.g. **0**, in order to connect with the local exchange and then dial the **outside party's number**.



If you hear an engaged tone, hang up the phone.



Pick up the phone again.



Dial \* 9 1  
You will hear a confirmation tone



Hang up the phone.

The server will be trying to establish a connection with the number you have

selected for the period of time determined in the computer program. The number (1-10 times) and the frequency (every 1-30 minutes) of repetitions are determined as well. After the connection has been established, your telephone will ring with a calling ringtone. If you are having a telephone conversation at that moment, you will hear an offering tone informing you about an incoming call. At the same time, the outside party will hear a voice announcement defined in the computer program, e.g. *Your call is being connected, please wait...* If you fail to answer the call within the time defined in the program (10-100 seconds), the server will disconnect it, at the same time cancelling the booked service.



In order to cancel the booked service, dial  
All booked external calls will be cancelled.



#### **4.2.13 Booking a call to any external number**

If you want the server to connect you with an external number, you may book such a call. Thanks to this option, you will not have to dial the same number repeatedly if the user is engaged. The server will be trying to establish a connection with the selected number.

If you wish to establish a connection with any number:



Pick up the phone.  
You will hear a dialling [tone](#).



Dial You will hear a confirmation tone.



Dial the number of the outside party (without the trunk lines bunch number) you wish to call (up to 14 digits), e.g. 585558800.



Hang up the phone.

The server will be trying to establish a connection with the number you have selected for the period of time determined in the computer program. The number (1-10 times) and the frequency (every 1-30 minutes) of repetitions are determined as well. After the connection has been established, your telephone will ring with a calling ringtone. If you are having a telephone conversation at that moment, you will hear an offering tone informing you about an incoming call. At the same time, the outside party will hear a voice announcement defined in the computer program,

e.g. *Your call is being connected, please wait...* If you fail to answer the call within the time defined in the program (10-100 seconds), the server will disconnect it, at the same time cancelling the booked service.



In order to cancel the booked service, dial  again.

All booked external calls will be cancelled.

#### **4.2.14 Booking a call to any external number at a specific time**

If you want the server to connect you with any external number at a specific time, you may book such a call. The server will book the trunk line at a specific time and will try to establish a connection with the selected external number.

If you wish to establish a connection with any external number:



Pick up the phone.

You will hear a dialling [tone](#).



Dial  **HH MM**,

where: **HH** – hour within the range of 00-23, **MM** – minutes within the range of 00-59. You will hear a confirmation [tone](#).



Dial the number of the outside party (without the trunk line bunch number) you wish to call (up to 14 digits), e.g. 585558800.



Hang up the phone.

The server will be trying to establish a connection with the number you have selected for the period of time determined in the computer program. The number (1-10 times) and the frequency (every 1-30 minutes) of repetitions are determined as well. After the connection has been established, your telephone will ring with a calling ringtone. If you are having a telephone conversation at that moment, you will hear an offering tone informing you about an incoming call. At the same time, the outside party will hear a voice announcement defined in the computer program, e.g. *Your call is being connected, please wait...* If you fail to answer the call within the time defined in the program (10-100 seconds), the server will disconnect it, at the same time cancelling the booked service.





In order to cancel the booked service, dial  
All booked external calls will be cancelled.

#### 4.2.15 Speed dialling

The server offers speed dialling possibility thanks to the bank of short numbers common for all server users. After the short number has been selected, the server will establish a connection with the number recorded in this entry. The bank may contain up to 1000 numbers. Each speed dial number may be composed of up to 16 digits, each real number - up to 24 digits. The numbers are entered using the computer program (see: *Call distribution → Speed dialling*). External numbers must be preceded by the number of the trunk lines bunch through which the connection is to be established (**0**, **\*81,...,\*84**) or by the trunk line number, e.g. **\*80a\*b\*c#**.

As a standard, [access to the server functions](#) is gained by pressing the **\*** key. In this case, speed dial numbers should be selected by pressing the **#** key. If, according to the settings, the server functions are accessed “after pressing #” or “with no special symbol,” the speed dial number should always be selected by pressing **\*\***.

If you wish to establish a connection with the selected speed dial number:



Dial **# X..**, where **X..** stands for the speed dial number defined in the computer program (up to 16 digits).



A connection with the selected number recorded in the form of a speed dial number will be established.

It is also possible to define up to 9 individual speed dial numbers. In order to record an individual speed dial number in the server:



Dial **\* 8 9 X TEL**,  
where **X** stands for the memory number within the range of 1 to 9  
**TEL** – external number, e.g. **\*89 1 585558800**



After hanging up the phone, the number will be memorised.

In order to use an individual speed dial number:



Dial **\* 9 1 X**,  
where **X** stands for the memory number within the range of 1 to 9



A connection with the selected external number recorded in the form of a speed dial number will be established.

#### 4.2.16 Virtual extensions

The server makes it possible to define virtual extensions. **Virtual extensions** are the extensions having their own extension numbers (assigned by the installer) within the server numeration plan along with the related privileges. However, the virtual users do not physically have their own telephones. In order to make a phone call, a virtual user needs to log onto any telephone connected to the server. Then, using their own privileges, they make a call on their own account. The system for users logging into any telephone applies to all server users having an individual password (i.e. both virtual and physical ones).

The total number of extensions (i.e. 1,000) is the total of physical and virtual extensions. For instance, a server with 40 extensions may additionally have 960 virtual extensions.

Virtual extensions may log into any extension (telephone) for a specific time or until cancellation (logging out). They may also make one-off external calls and change their individual access codes. The **CODE** is assigned by the installer or by the server maintenance personnel in the computer [program](#) (*menu: Extensions → Phone blocking*). After the code has been made available, the user may change it using the telephone (\***785 function**).

In order to log into any telephone (extension) until cancellation (until the user logs out) and to use your own privileges and your own account:



Pick up the phone.  
You will hear a dialling tone.



Dial  **TEL CODE**,  
where: **TEL** – your own extension number within the server  
**CODE** – your own, individual access code (1-6 digits).  
You will hear a confirmation [tone](#).



Hang up the phone.  
You may now use your own privileges and make calls on your own account.

In order to log out of a given telephone and to cancel the \***782 TEL CODE** function (see: above):



Pick up the phone.

You will hear a dialling tone.



Dial **\* 7 8 3 CODE**,

where: **CODE** – your own, individual access code (1-6 digits).

You will hear a confirmation [tone](#).



Hang up the phone.

Logging out will take place as well when the user logs into another extension (telephone).

In order to log into any telephone for a specific **time T** and to use your own privileges and your own account (as in the case of the **\*782 function**):



Pick up the phone.

You will hear a dialling tone.



Dial **\* 7 8 4 TEL CODE**,

where **TEL** – your own extension number within the server

**CODE** – your own, individual access code (1-6 digits).

You will hear a confirmation [tone](#).



Hang up the phone.

The user will be logged out automatically after the time **T**.

**Time T** (from 1 to 256 s) is set by the installer or by the server maintenance personnel in the computer [program](#) and it functions as a global parameter for all server users. The time is always counted after the phone has been hung up. If the phone is picked up before the time limit has expired, the time is counted anew after the phone has been hung up again.

(see later on: *Notes on the functionality of the virtual extensions*).

#### 4.2.17 Blocking outgoing external calls from the phone

If you do not want anyone to make calls from your telephone while you are absent, you may block it using an individual code (max. 6 digits). The first code (*Extensions → Phone blocking*) and the privilege (*Extensions → Service classes*) to use this function are granted by the installer or by the server maintenance personnel in the computer [program](#).

In order to block outgoing external calls using your telephone:



Pick up the phone.  
You will hear a dialling tone.



Dial **\* 7 8 1 CODE**,  
where CODE is a valid code (1-6 digits).  
You will hear a confirmation [tone](#).



Hang up the phone.  
Your phone has been blocked on outgoing external calls.

In order to unblock outgoing external calls using your telephone:



Pick up the phone.  
You will hear a dialling tone.



Dial **\* 7 8 0 CODE**,  
where CODE is a valid code (1-6 digits).  
You will hear a confirmation [tone](#).



Hang up the phone.  
Your phone has been unblocked on outgoing external calls.

You may change your individual access code to a new one at any time.



Dial **\* 7 8 5 CODE CODE-2 #**,

where: **CODE** – your old code (1-6 digits),  
**CODE-2** – your new code (1-6 digits).

Press # to confirm.

It is possible to activate automatic blocking and unblocking of selected extension phones when the server operation mode is changed. This option is configured in the server individually for each user (*Extensions → Traffic classes*).

#### **4.2.18 Logging a virtual extension for the duration of a single external**

## *call*


A server user may make an external phone call using a phone that is not authorised for outgoing external calls or is blocked with an individual code. Such a call will be ascribed to the account of the user using this service.

If you want to use (on your own account) the telephone that is blocked or unauthorised for external calls:



Pick up the phone.

You will hear a dialling tone.



Dial **TEL CODE**,

where: **TEL** is your extension number (if you have a 2-digit extension number, e.g. 22, dial 22. If you have a 3-digit number, e.g. 222, dial 222).



**CODE** stands for your individual code (max. 6 digits) used to block the telephone.

You will hear a dialling tone of a local exchange.

This function requires the user using this service to be authorised to use the selected trunk lines in the computer [program](#). Otherwise, they will not be able to make an external call.

### **4.2.19 Notes on the functionality of the virtual extensions**

- a. Each physical user (having their own extension/telephone) may use the virtual extension functionality by forwarding their privileges to any other telephone.
- b. If a physical extension has the functions of a proprietary phone, using the virtual extension functionality the proprietary phone functionality may be forwarded to other telephones and the user may log into them.
- c. Each virtual extension has its own dialling number. After the virtual extension user logs into the selected telephone, the server directs all incoming calls there (internal, incoming DISA and DDI calls).
- d. Virtual extensions may forward calls as all other extensions. The only thing that needs to be done is to enter the numbers to which the calls are to be forwarded into the **Call forwarding** table (*menu: Extensions → Call forwarding*). If an extension is logged out, the “unconditional” call forwarding and the “when no answer” call forwarding are active. If an extension is logged in, all call forwardings are active.
- e. In the case of an incoming call to a virtual extension that is logged out and

- has no “when busy” call forwarding set, the caller will hear an “unavailable” tone.
- f. The codes are defined in the computer program by the system administrator. A user may change the assigned code using the telephone.
  - g. Logging a virtual extension into any extension/telephone results in automatic logging out (if it is logged in) of the previous extension/telephone.
  - h. If a physical extension user is logged into any other terminal (telephone), the functionality of their telephone for outgoing calls remains unchanged, unless somebody else logs into their telephone.
  - i. If a telephone is ringing, capturing this call requires the number of the called user to be provided. This number is the number of a physical extension or the number of a virtual extension user currently logged into a given telephone.

#### ***4.2.20 Analogue FLASH on trunk lines***

In its basic meaning, **FLASH** (a short calibrated pause) reassigned tone dialling ([DTMF](#)) disconnected by the system after a call has been initiated. This function is used when during an ongoing call you want to use a different server service, e.g. to put the call on hold ([HOLD](#)), to [transfer](#) the call to another user, etc. Pressing the **FLASH** button is interpreted by the server as a short “hanging up,” not long enough to end a call.

The second **FLASH** function (the so-called analogue FLASH) – pressing this button in the course of an external call results in a “short disconnection” of the trunk line. In this way, the server sends the **FLASH** signal to the local exchange (for some local exchanges this is a necessary signal to start using their additional functions).

If you want to send the **FLASH** signal to the local exchange:



Press **Flash**, **\***, **1** during an external call.



You may now use the additional functions offered by the local exchange.

## 4.3. Conferences

A conference may be attended by internal (extension) and external (outside) users.

### Possible conference configurations:

- **conference room** – extensions and outside parties (limit of participants depends on the licence)
- internal conference for **8 extensions**
- **1 outside party - 7 extensions**
- **2 outside parties - 1 extension**
- **circular conference** – conference for a defined Hunt Group (up to 8 extension users).

### 4.3.1 Conference rooms

Proxima IP PBX Server and Libra PBX Server make it possible (with the conference rooms licence) to create conference rooms by the extension users having proper privilege *Conference room reservation* granted in the computer program (*menu: Extensions → Service classes*).



The number of conference rooms is not limited by the licence. The licenced limit concerns only the maximum number of participants in a single conference.

#### 4.3.1.1 Types of conference rooms

##### Single conference room with reservation time

Single conference room is a conference room in which a conference starts after the user who has reserved the conference room enters. A conference in this room can be established only once. The conference room reservation can be made for up to 31 days (the *Conference room reservation time* is defined in the computer program).

If the first participant entering the conference room is not the user who has reserved it, they will hear the following announcement “*you are the only person in the conference room. Wait for other participants.*” The announcement is played cyclically.

After the above announcement, an announcement/melody set in the computer

program (*Common settings → Global settings*) is played.

The next users, who have neither made a conference room reservation and want to enter the conference room, will hear the announcement: „*you are in the conference room. Wait for other participants.*”

The conference is established (and waiting participants joined to it) when the person who has reserved the conference room enters.

When the conference room is entered by the user who has reserved it, all the conference participants hear the announcement: “*You will be connected with the conference room after the signal.*”

Every next participant joining the conference after the person who has reserved the conference room will hear the same announcement before joining the conference.

The conference ends when the participant who has reserved the conference room hangs up (end of the connection). The remaining conference participants hear the announcement “*End of the conference,*” after which they are disconnected and the conference room is deleted.

### **Multiple conference room with reservation time**

Multiple conference room is a conference room that does not require the presence of the user who has reserved it. It can be used multiple times within the expiry date setup in the computer program.

The first and only participant entering the conference room hears the following announcement “*you are the only person in the conference room. Wait for other participants.*” The announcement is played cyclically. After the above announcement, an announcement/melody set in the computer program (*Common settings → Global settings*) is played.

The announcement: “*You will be connected with the conference room after the signal*” is being played for the participants joining the conference room and the conference is established.

The conference ends when the last conference participant hangs up (end of the connection). The conference room is not deleted and remains available for up to 31 days (the *Conference room reservation time* is defined in the computer program.)

### 4.3.1.2 Conference room reservation

A conference room reservation can be made only by the user with the *Conference room reservation* privilege (set in the computer [program](#) in: *Extensions → Service classes*).

If you want to make a conference room reservation:



Pick up the phone.  
You will hear a dialling tone



Dial **\* 8 5**.  
You'll hear the announcement:

*“Conference room reservation; to make a multiple reservation press 1; to make a single reservation press 2; to check active reservations press 3; to delete a reservation press 4.”*



Dial **1** to make a multiple reservation  
Dial **2** to make a single reservation

You will hear the following announcements:

after dialling 1:

*“Multiple reservation. Access number \*86, room number [room number automatically generated], PIN code [PIN code automatically generated], valid [reservation time] days – reservation active.”*

after dialling 2


*“Single reservation. Access number \*86, room number [room number automatically generated], PIN code [PIN code automatically generated], valid [reservation time] days – reservation active.”*

The conference room reservation time (validity) is set up in: *Common settings → Ringtone and server times → Server times* (1-31 days, 7 days by default).

The received room number and PIN code should be distributed to the conference participants, for instance by group short text messages (SMS) or ordinary messages in Platan CTI app, by e-mail or any other medium.

### 4.3.1.3 Checking active reservations

If you want to check your active conference room reservations:



You'll hear the announcement:


*“Conference room reservation; to make a multiple reservation press 1; to make a single reservation press 2; to check active reservations press 3; to delete a reservation press 4.”*



You will hear the information about the conference rooms you have reserved, their numbers and PIN codes.


### 4.3.1.4 Deleting reservations

If you want to check your active conference room reservations:



You'll hear the announcement:

*“Conference room reservation; to make a multiple reservation press 1; to make a single reservation press 2; to check active reservations press 3; to delete a reservation press 4.”*



You will hear the announcement: *“Enter room number”*



Enter room number, after which you'll hear: “*Enter PIN code.*”



Enter PIN code for this room, after that you'll hear “*Reservation deleted.*”



The conference room reservation may be deleted only by the user who has reserved a given room.



The multiple conference room reservation may be deleted during the ongoing conference, but the conference room will not be deleted before all conference participants hang up.


#### 4.3.1.5    Entrance to the conference room

If you want to enter the conference room:



Pick up the phone.

You will hear a dialling tone



Dial **\*** **8** **6**

You will hear the announcement: “*Entrance to the conference room. Enter room number.*”



Enter room number. Then you'll be asked to enter PIN: “*Enter PIN code.*”



Enter PIN code for the conference room. You'll hear the information depending on the conference room type and the current number of conference participants.



If in the computer program the option “*Do not require PIN when re-entering a given conference room*” is ticked, the participants, after the first authorisation, do not have to enter the PIN code to enter the multiple conference room. The same applies for participants who exit the ongoing conference and want to re-join it.

### 4.3.2 Internal conference for 8 extension users

A conference may be opened and initiated only by an extension user having proper privileges (*Transferring internal calls*) granted in the computer [program](#) (*menu: Extensions → Service classes*). Other users may be added only by the user who has opened the conference.

In order to establish a conference connection:



Pick up the phone.



Dial the server **extension number**.

When the called user answers, you may add other ones. In order to do this:



Dial **Flash TEL**,

where TEL stands for the extension number of the server user.

The waiting user will hear a voice announcement or a tune, depending on the settings defined in the computer program (see: [HOLD function](#)).



After the connection with this user has been established, dial **\*** **7**

When the user picks up the phone, a conference connection involving three users is established.

Every other user is added in a similar manner by dialling:



**TEL** (and after the connection has been established) **\*** **7**



When subsequent users are being added to the conference, the call is not put on hold (no voice announcement is heard).

The **\*7** sequence may also be pressed before the extension number is dialled (**Flash – \*7 – extension number**). In this case, when the added user picks up the phone, the server instantly establishes a conference.

### 4.3.3 Conference calls with outside party

A server extension user may add up to 7 extension users to an ongoing external call. A conference may be opened and initiated only by an extension user having proper privileges (*Transferring internal calls, Transferring calls to outside parties*) granted in the computer [program](#) (menu: *Extensions → Service classes*). Other users may be added only by the user who has opened the conference.

If you wish to add other extension users to the conversation held with an outside party:



Press



You will hear a continuation tone.



Dial the number of an extension user you wish to add to an ongoing conversation.



You will hear a ring-back [tone](#).

The waiting outside party will hear a voice announcement or a tune, depending on the settings defined in the computer program (see: [HOLD function](#)).



After the connection has been established, dial in order to add this user to the conference. You may also add them to the conference after a short conversation.



After the conference has been established, you may talk to both the external and the extension user.

**The \*7 sequence may also be pressed before the extension number is dialled (Flash – \*7 – extension number).** In this case, when the added user picks up the phone, the server instantly establishes a conference.



The server may handle up to 16 conferences at the same time.

#### 4.3.4 Two outside parties – one extension user conference

If you are having a telephone conversation with an outside party, you may open a conference with another trunk line, e.g. with the mobile phone of an employee staying outside the company's premises. A conference call with a trunk line is rated as any other outgoing call. The user opening a conference call must be authorised in the computer program to **use the access number** and to **transfer calls** (*menu: Extensions → Service classes*).

If you are having a telephone conversation with an outside party and you wish to open a conference with another outside party (at the expense of your server):



Press **FLASH**.

You will hear a [continuation tone](#).



Dial your own extension number – **TEL**.



Hang up the phone. Your party has been put on hold – **HOLD**.



Pick up the phone.

Select another trunk line, e.g. 0 or \*80\*a\*b\*c, and dial the number of the outside party you want to include in the conference.



When the called party answers, press **FLASH**.

You will hear a [continuation tone](#).



Enter the **Access number** (it is a security code defined in the computer [program](#)): *Common settings → Calls*. This number must differ from those listed in the numbering plan for users, the Hunt Group, etc.).

The server has established a conference.

If an internal user participates in the conference, the talktime is unlimited. If the call is held without the participation of an internal user, its duration will equal the time predetermined in the computer [program](#) with the possibility of [prolonging](#) it.

#### 4.3.5 CIRCULAR conference

This option makes it possible for a call and a conference involving several extension users to be held at the same time. Up to 8 users (including the initiating user) may participate in a **CIRCULAR** conference.

The called **CIRCULAR** conference participants have to be defined in the computer [program](#) as a **Hunt Group**. The **CIRCULAR** conference will be established for the first 8 users within a given **Hunt Group**. This kind of conference may be used for example by: department managers, security guards in various sections of a building, etc.

In order to establish a **CIRCULAR conference** connection:



Every called user's telephone rings for a defined **Hunt Group ringtones time** (*Common settings → Ringtones and server times → Ringtone times; default setting: 60 s*) or until the phone is picked up (or until the teleconference is finished – if it happened earlier). The called user joins the conference automatically by picking up the phone. They may also quit the call at any time by hanging up the phone.

If the user called within the **CIRCULAR** conference is having another telephone conversation, they will hear an offering tone in the background. When they hang up, the phone will ring back. After picking up the phone, the said user is added to the conference.

#### **4.4. Additional server functions available from the telephone**

#### **4.4.1 Wake-up call (reminder)**

The term wake-up call is just a matter of convention because this function consists in the server “reminding” the user about the tasks that need to be done at a specific time. This service may be used in 2 modes: **single** and **multiple**. These two modes may function independently, i.e. the same user may use both **single** and **multiple** wake-up calls. To activate this service, a user must have the service class with the *Wake-up calls* option assigned.

If you want to book a **single wake-up call**:



Pick up the phone.  
You will hear a dialling tone.



where: T = day of the week

0 – everyday	4 – Thursday
1 – Monday	5 – Friday
2 – Tuesday	6 – Saturday
3 – Wednesday	7 – Sunday

**hh** – hour, **mm** – minute



After hearing a confirmation tone, hang up the phone.

The user may have several “wake-up calls” booked at the same time. If a single wake-up call is booked in a daily mode, the server will provide this service as soon as possible.

If you want to book a **multiple wake-up call**:



Pick up the phone.

You will hear a dialling tone.



\* 7 3 2

Dial T hh mm,

T – day of the week (*see:*  
Weekdays).



After hearing a confirmation tone, hang up the phone.

### Wake-up call in practice:



For example, after dialling **2 12 44**, a single wake-up call is booked for **Tuesday at 12:44 pm**.



***Ring !!!*** The phone rings with an alarm tone...



Pick up the phone.

You will hear a voice announcement or a tune, depending on the settings defined in the computer [program](#).



Hang up the phone.

If a **wake-up call** is not answered, the phone will stop ringing after the period of time defined in menu *Common settings* → *Ringtones and server times* → *Ringtone times*.

### If you want to delete the previously booked wake-up calls:



Pick up the phone.

You will hear a dialling tone.



Dial



Hang up the phone.

All previously set wake-up calls have been deleted.

#### 4.4.2 *Changing server operation modes manually*

This function is used to switch on the server **operation mode A-F** at the time and on the day of the week different than programmed in the server operation **mode table** (the programming of server operation modes A-F and the related times, e.g. of the night operation mode, is described in the *ProximaWeb/LibraWeb program operation manual*).



The operation mode may be changed manually by extension user authorised in the [program](#) (*Extensions → Privileges*).

If you wish to activate the **operation mode A** manually:



Pick up the phone. You will hear a dialling tone.



Dial

The server starts working in mode A.



Hang up the phone.

If you wish to activate the **operation mode B** manually:



Pick up the phone. You will hear a dialling tone.



Dial

The server starts working in mode B.



Hang up the phone.

If you wish to activate the **operation mode C** manually:



Pick up the phone. You will hear a dialling tone.



Dial

The server starts working in mode C.



Hang up the phone.

If you wish to activate the **operation mode D** manually:



Pick up the phone. You will hear a dialling tone.



Dial \* 7 4 5

The server starts working in mode D.



Hang up the phone.

If you wish to activate the **operation mode E** manually:



Pick up the phone. You will hear a dialling tone.



Dial \* 7 4 6

The server starts working in mode E.



Hang up the phone.

If you wish to activate the **operation mode F** manually:



Pick up the phone. You will hear a dialling tone.



Dial \* 7 4 7

The server starts working in mode F.



Hang up the phone.

If you want to switch off the automatic change of server operation modes and leave the server in the current operation mode:



Pick up the phone. You will hear a dialling tone.



Dial \* 7 6 4

The server will switch off the automatic change of operation modes and will start working in the last operation mode set.



Hang up the phone.

If you want to switch on the automatic change of server operation modes:



Pick up the phone. You will hear a dialling tone.



Dial **\* 7 6 5**

The server will switch on the automatic change of operation modes and will start working according to the modes defined in the computer [program](#).



Hang up the phone.

You may “manually” return (switch over) to the mode currently active in the program by entering the number of this mode. The server will change the mode automatically according to the times programmed in the computer program.

#### **4.4.3 BABYSITTER function (*remote room listening in*)**

If the **babysitter** function is active, any extension telephone enables you to control the situation in the room in which the telephone with the babysitter function on is located. This function is available for the server users and for the outside parties handled by the server in the [DISA](#) or [DDI](#) mode.

If you want to use the **babysitter** function:



Pick up the phone in the room you want to control.  
You will hear a dialling tone.



Dial **\* 7 4 0**



Place the receiver next to the telephone or switch on the speaker circuit (SP-PHONE).



You have activated the **babysitter** function.

If you are using a proprietary phone, the **LISTENING IN** message will be displayed.



Pick up another telephone through which you want to establish a connection with the “babysitter” telephone or make an external call to the server if the incoming calls are handled in the [DISA](#) or [DDI](#) mode.



Dial the **babysitter** telephone number. The server will let you hear what is happening in the controlled room.



The service will be deactivated when you hang up the **babysitter** telephone or when you switch off the speaker circuit.

#### **4.4.4 DO NOT DISTURB function**

When the **do not disturb** function is active, all users calling you will hear an engaged tone for the period of time defined in the computer [program](#) or until this function is manually deactivated. At the same time, you may make outgoing calls with no restrictions.

If you want to activate the do not disturb function:



Pick up the phone.  
You will hear a dialling tone.



Dial

Hang up the phone.

You have activated the **do not disturb** function.



If you are using a proprietary phone, the DO NOT DISTURB message will be displayed.

If you want to deactivate the **do not disturb** function:



Pick up the phone.

You will hear a dialling tone.



Dial



Hang up the phone.

You have deactivated the **do not disturb** function.

If this function is not deactivated, it will be cancelled automatically after the time defined in the computer [program](#) (menu: *Common settings* → *Ringtone and server times* → *Server times*). By default: 930 seconds.

#### 4.4.5 MCID – Malicious Call Identification

Malicious call identification is available for digital lines only – this function makes it possible to register the numbers of called and calling users as well as the dates and times of calls. Malicious, troublesome or threatening calls may be registered after this function has been activated in the telephone. The data registered by the telecommunications operator by means of the additional MCID function is at the disposal of the operator that makes it available to the state authorities performing the security and public order protection tasks within the scope and on terms stipulated by the relevant acts of law.

In order to mark a given call as “malicious,” the following should be done during a call:



Dial

#### **4.4.6 External devices control (I/O)**

Apart from typical connection-related functions, Proxima / Libra PBX Server may control other systems and external devices, thus becoming an important part of the intelligent building system. It can control gates, furnace, lighting, sprinklers, electric shutters, schoolbells etc. Privileged users may call the defined server number(s), and after entering a special code, activate or deactivate previously programmed device(s).

External devices may be also controlled according to the programmed schedule (see: *Common settings* → *External devices control (I/O)* → *Time control*). For example, the light can be periodically switched on and off in one or several rooms to simulate someone's presence in the building. If an external alarm system is connected to the server, it may be also remotely activated or deactivated.

The full programming of external devices control is done in the computer program (see: *Common settings* → *External devices control (I/O)*). You have 8 relays at disposal in Proxima and Libra servers. The relays are located on the external adapter, which is an optional equipment. The adapter serves to connect external devices to Proxima IP PBX Server / Libra PBX Server.

The devices may be controlled by an extension user having relay access number and activation/deactivation codes. If a trunk line works in DISA mode, the external devices control is also available for external users, whose numbers have been defined in the server as privileged to control external devices. A privileged user, calling to the server from outside, may dial the given relay access number during the announcement. After hearing a confirmation tone – they activate or deactivate the device by entering the required code on the phone keypad. For every command separate codes may be defined in the [computer program](#).

The external devices control may be also done by text messages sent from the mobile phone numbers defined in the [computer program](#). In order to control the external device with a text message, send a following text message:

**STERxy**

where:

x: 1-8 output number,

y: 0-deactivation, 1-activation, 2-temporary activation.

Additionally, 8 automatic external devices activation/deactivation settings can be defined in the server, e.g. a device may be activated on a defined hour on a selected

day(s) and deactivated on another.

The programming of external devices control is described in the *ProximaWeb/LibraWeb program operation manual*.



Relay access numbers and codes are assigned by server administrator.

#### **4.4.7 Hotel features**

Proxima IP PBX Server and Libra PBX Server are compatible with the most popular hotel software; the list of compatible hotel applications is available on [www.platan.pl](http://www.platan.pl) website.

Thanks to the cooperation with the hotel application, a user can handle up to 8 room statuses, defined according to the individual needs:

Exemplary room statuses:

- 1 – room done,
- 2 – minibar refilled etc.

Room status handling in Proxima/Libra servers is available from the phone:

\*766 xxx – saving room statuses, where x is a single room status, e.g. \*766135 – saving status 1, 3, 5 for this room.

\*766 #x#x#x – deleting room statuses, where x is a single room status, e.g. \*767#1#5 – deleting status 1 and 5 for this room.

Example: \*766 1#32#4 – saving status 1 and 2 and deleting status 3 and 4 for a given room.

1. After dialling the prefix, the user will hear a continuation tone.
2. Dial \* or # to specify the type of operation (\* – setting status, # – deleting status).  
If you dial any other digit, the PBX server will beep 3 times and you will have to wait again for \* or #.  
Dialling \* or # will be confirmed with a continuation tone and you will go to item 3.
3. Dial the status bit number (1-8) to be set. The server produces a continuation tone and goes to item 4. If you dial a number from outside the range, the PBX server will beep 3 times and you will go back to item 2.
4. If you dial a correct number, you will hear a confirmation tone and go back to item 2.

## 4.5. Server programming using the telephone

Some of the functions offered by the server (e.g. **announcement recording, date and time setting**) may be programmed using the telephone in the **programming mode**.

In order to ensure stable server operation, it is recommended for the **programming mode** to be used only by an authorised user having necessary knowledge.

If you wish to activate the server **programming mode**:



Pick up the phone.



Dial – the server function activation mode is on.



Dial



Enter the **server access code**.

If the code you have entered is correct, you will hear a confirmation tone and the access to the server programming mode will be granted.



You exit the programming mode by pressing or when the telephone receiver is hung up for longer than 10 seconds.

### 4.5.1 Access code for server programming using the telephone

This code is necessary to access the server programming mode. **Default access code: 12345678**. It is recommended to replace the default code with your own one via the computer program (*menu: Administration → Password change*).



If an invalid code is entered, you will hear an engaged tone.

### 4.5.2 Setting up the server IP address using the telephone

In order to set up the server IP address using the telephone, you must enter the **server mode programming using the telephone \*708 “code” (default code: 12345678)** and set the IP address and the subnet mask using the following codes:

**41 “IP address” #** – setting the IP address, e.g. **41 192\*168\*1\*195#** (the server will be reset after programming),

**42 “subnet mask” #** – setting the subnet mask, e.g. **42 255\*255\*255\*0#** (the server will be reset after programming).



#### **NOTE**

*After the IP address has been entered using the telephone, the server will switch to port 80 by default.*

### **4.5.3 Announcement recording**

The server makes it possible to record 99 announcements. Total duration of all announcements: up to 30 hours. In order to record an announcement:



Pick up the phone.



Activate the server [programming mode](#) using the telephone.  
You will hear a confirmation [tone](#).



Dial **2 9 XX**,  
where **XX=01,02...99** stands for the announcement number



You will hear a continuous tone lasting for approx. 3 seconds.  
**After the tone, you may record your own announcement.**



After the announcement has been recorded, hang up the phone.

#### **Announcement numeration used in the course of recording**

1. – announcement 1/Music/wav;
2. – announcement 2/Music/wav;
3. – announcement 3/Music/wav;
4. – announcement 4/Music/wav;
5. – announcement 5/Music/wav;
- .
97. – announcement 97/Music/wav;
98. – announcement 98/Music/wav;
99. – announcement 99/Music/wav;

**Announcements may be recorded using .wav files.** This is done using the computer program only (*menu Common settings → Announcements*) via LAN.

In order to listen to the recorded announcement, dial [\\*741xxx](#) or [\\*701xx](#).

It is possible to use the same announcement to handle more than one trunk line. Therefore, multi-layered announcements may be created.

It is recommended to record an announcement for: **call booking** (no “silence”). The following message may serve as an example:

*“The server is establishing the connection. Please wait...”*

#### 4.5.4 Verification of announcements recorded by the user

In order to check (listen to) the recorded announcement:



Pick up the phone and dial  **XX**, where: **XX** stands for the announcement or tune number (*within the range of 1 to 99*).

The previous (by pressing “\*”) or the next (by pressing “#”) announcement/tune may be listened to while listening to a announcement or a tune without the need to hang up the phone. Apart from that, the **XX** announcement/melody may be listened to after pressing **XX**.

### SECOND METHOD

In order to check (listen to) the recorded announcement:



Pick up the phone and dial  **XXX**, where: **XXX** stands for the announcement or tune number according to the pattern below:

xxx=001	announcement 1;	xxx=013	announcement 13;
xxx=002	announcement 2;	:	
xxx=003	announcement 3;	xxx=098	announcement 98;
xxx=004	announcement 4;	xxx=099	announcement 99;
xxx=005	announcement 5;	xxx=100	melody 1;
xxx=006	announcement 6;	xxx=101	melody 2;
xxx=007	announcement 7;	xxx=102	melody 3;

xxx=008	announcement 8;	xxx=103	melody 4;
xxx=009	announcement 9;	xxx=104	ring-back tone;
xxx=010	announcement 10;	xxx=106	routing;
xxx=012	announcement 12;	xxx=107	three tones;



Hang up the phone.



The phone will ring with a calling tone. After picking up the phone, the recorded announcement may be listened to.



The \*741xxx function may also be used for independent telephone volume control if the telephone ringing is too quiet or too loud.

#### **4.5.5 Date and time setting**

The current time and date may be set (or corrected) in the server. This may be done using either the computer program or the telephone. In order to set the date and time using the telephone, the server access [code](#) must be known and the server [programming mode](#) must be activated.

If you want to set or correct the server time and you are in the [programming mode](#):



Dial



Dial six digits defining the current time.

E.g. to set the time to 13:27:00, the following number should be dialled:



If you want to set or correct the server date and you are in the [programming mode](#):




Dial



Dial seven digits defining the date: YY MM DD T

e.g.: to set the date to: 2012.02.16 Thursday, the following number should be dialled:



Where:

**12** – year 2012

**02** – February

**16** – day of the month

**4** – Thursday (**1** – Monday,... **7** – Sunday)

#### 4.5.6 Deleting active bookings

If all bookings programmed in the server need to be deleted, this operation may be performed using the telephone. In order to do it, the server access [code](#) must be known and the [programming mode](#) must be activated.

If you want to delete all active server bookings:



Pick up the phone.

Activate the server [programming mode](#).



Dial



You will hear a confirmation [tone](#).



Hang up the phone.

All bookings programmed in the server have been deleted.

#### 4.5.7 Special service functions

The server has certain special codes available in the programming mode. These codes may be useful as far as the server maintenance services or the measurement purposes are concerned.

In order to use the functions below, the server access [code](#) must be known and the server [programming mode](#) must be activated.

- |  |           |
|--|-----------|
| 1. Generating the 1kHz model signal          | – code 32 |
| (active until you exit the programming mode) |           |
| 2. Generating the fax signal                 | – code 33 |
| (active until you exit the programming mode) |           |

## 5. Proprietary phones

The server is supported by direct dialling consoles and KX-T76xx and KX-DTxxx series digital proprietary phones. Digital proprietary phones are connected to the server by means of a single pair of wires. More information about the connection of proprietary phones to the server is available in **Part I** of the server documentation describing the server installation procedure.

[Section 5.1](#) provides information regarding the operation and configuration of digital proprietary phones.

### 5.1 Digital proprietary phones

In order to streamline work at the intermediate station (or at any other station important for the communication system, e.g. at the dispatching station, in the secretary's office, etc.), a proprietary phone is recommended. This type of phone facilitates observation of the call traffic and makes both transferring calls and using the server services easier. LEDs located next to the phone keys signalise whether the trunk/extension line is idle or engaged. By pressing one key only, a user may call another user or activate a server service. In addition, the proprietary phone display shows messages about the current server status (active function type, time, operation mode, etc.)

The proprietary phone is also equipped with a direct dialling console making speed connection with extensions possible (by pressing one button).

As far as the proprietary phone is concerned, internal, external, outgoing and incoming calls may be handled and the services offered by the server may be provided in two ways:

1. After the correct function code has been entered using the numerical keypad;
2. By pressing the key to which a given service or number is assigned.

To use certain server services, each user must be properly authorised. User competences are defined by the administrator in the computer [program](#) while programming the server.


In the Proxima server, digital proprietary phones are supported by the **Proxima-DSYS2** and **Proxima-DSYS4** cards, and in the Libra server - by the **Libra-DSYS4** and the **Libra-DSYS8** cards.

In the case of digital proprietary phones, buttons and their respective LEDs can be

programmed as needed. A button may be assigned to any server function, user's number or to any symbol that can be dialled from the keypad. The function keys pre-programmed permanently are described below:

**TRANSFER****Transferring calls in the background**

1. In the case of an incoming call (the phone is ringing), you may, using this button, transfer the call directly to the entered number or to the voicemail without answering the phone.
2. During a call, this button functions as a regular **FLASH**.



**Panasonic® KX-DTxx, KX-T7633 proprietary phone**

**MESSAGE**

## Displaying the missed call information

1. In the case of a missed incoming call, a LED located next to this button will switch on to inform you about such an occurrence. The phone display will show the information about who called and when.
2. By pressing this button, you may call the speaker circuit of a selected proprietary phone, provided that you have the Speakerphone call privilege granted.

**REDIAL**

### Redialling the most recently dialled external number

Pressing this button results in redialling an external number. The server “\*90” function is ascribed to this button.

**AUTO DIAL**

### Displaying the booked call information

1. When a call is booked (functions \*92, \*94 and \*95), the LED ascribed to this button is active.
2. By pressing the button, you activate the \*92 function, i.e. establish a connection with the recently dialled external number.

**HOLD**

### Putting an ongoing call on hold

By pressing this button, you put the call on hold for the period of time defined in the computer program (10-320 s).

To resume the call, you must press the HOLD button again.

**INTERCOM**

### CIRCULAR conference

After you press this button, you may initiate a CIRCULAR conference by dialling the Hunt Group number.

**CONF**

### Conference call

Thanks to this button, you may establish a conference without the need to dial the \*7 sequence.

**AUTO ANSWER**

## Answering calls automatically

When the phone is hung up – if the AUTO ANSWER button is pushed in, a calling extension user and an outside party will be automatically switched to the speakerphone (after 1 ringtone). This function is active until cancelled. In order to deactivate it, the same key must be pushed again. If active, the AUTO ANSWER key flashes red.

**MUTE**

### Mute – one way sound off

When the phone is picked up or the speakerphone is on – its role is to switch off the transmission using the proprietary phone to the user with whom a conversation is held (switching off the microphone). You can hear the other person but this person cannot hear you. Pressing this button again restores the two-way communication.

**SP-PHONE**

### Switching the speakerphone on/off.

Makes it possible to hold a conversation without picking up the phone.

1. *The phone is hung up:* when the phone rings, you switch on the speakerphone by pressing this button. To switch the call to the receiver, you must pick it up. If the receiver is not picked up, the speakerphone will be switched off and the call ended after the SP-PHONE key has been pressed again.
2. *During a call:* pressing this key transfers the call from the telephone receiver onto the speakerphone.

If the speakerphone is activated, the SP-PHONE button is backlit red.

If you tick the **Auto pick up** in the computer program option (*menu: Extensions ➔ Privileges / Proprietary*), the speakerphone is switched on automatically when the speed dialling button is pressed.

## Additional proprietary phone settings

### NAVIGATOR KEY KNOB



When the phone is hung up, **in a standby mode:**

Adjusting the proprietary phone LCD contrast.

When the phone is hung up **and is ringing:**

Used to adjust the volume of the proprietary phone ringtone.

When the phone is picked up or the SP-PHONE is active:

Used to adjust the volume of the proprietary phone speaker and to adjust the volume of a conversation.

**Hands-free headsets** – in the case of **KX-DTxxx KX-T76xx** series proprietary phones, the hands-free headset is switched on via the computer [program](#) or via the telephone, using the codes below:

- \***762** – hands-free headset on
- \***763** – hands-free headset off

**KX-DT5xx series digital proprietary phones and consoles are presented below**

Technical specification	KX-DT546	KX-DT543	KX-DT521
Photo			
LCD	Graphical 6 lines x 24	Graphical 3 lines x 24	Graphical 1 line x 16
Display backlight	yes	yes	no
LED-backlit function keys	24 two-colour	24 two-colour	8 two-colour
Optional installation of the KX-DT590 line add-on module	yes	yes	no

Technical specification	KX-DT590
Photo	
Device type	Proprietary console
Connection	single-pair
LED-backlit function keys	48 two-colour
Supported by	Libra PBX Server

### 5.1.1 *Messages on the digital proprietary phone display*


When a proprietary phone is used, various messages are shown on the display. These messages may be divided in the following manner:

- messages displayed when the phone is hung up,
- messages displayed when the phone is picked up,


Messages are written in the Latin alphabet. Polish letters with diacritics are automatically changed into the similar ones found in the Latin alphabet (ą into a, ę into e..., etc.).

#### MESSAGES DISPLAYED WHEN THE PHONE IS HUNG UP


- ✓ Date, time and the server operation mode:




- ✓ When the phone is ringing – internal call – description of the calling party (*computer program*, menu: *Extensions → Privileges*).



- ✓ When the phone is ringing – connection through [DISA](#) (trunk line description or [CLIP](#)):




- ✓ Phone is ringing – incoming connection from external line. Mode: [Announcement](#) (trunk line description or [CLIP](#)):



**The following messages are also displayed:**  
Group call and **Door phone calling** along with the terminal description.


- ✓ After the \*760 ([do not disturb](#)) and the \*781 ([trunk line blocking](#)) functions have been activated, the proprietary phone display shows the following messages respectively: **Do not disturb** or **CO block**.




- ✓ In the case of an [unconditional](#) call forwarding to another extension or external number, the following message will be displayed:
  - for an extension number: where xxx stands for an extension number

**I'm at: xxx**

– for an external number:

**I'm at: 0...**

- ✓ In the case of a missed call, the LED ascribed to the **MESSAGE** button flashes, and the information about the missed call is shown on the display:
  - **Extension XXX** (internal call)
  - **CO 0585558845** (external call from the line according to the description or CLIP)
  - **DISA 0585558845** (external call from the line according to the description or CLIP)



Depending on “who called,” the following messages may also be displayed:

**Called: Hunt Group.**

**Called: Door phone**

- ✓ When you switch on the server, the display of the proprietary phone supported by the **DSYS** card shows the information about the software version of this equipment card and specifies to which card equipment a given device is connected.


T2 v 00.33

## MESSAGES DISPLAYED WHEN THE PHONE IS PICKED UP


- ✓ Dialling – the dialled numbers are shown on the display:

0585558800

- ✓ After a connection has been established (a call has been initiated), the current call duration and the call start time are displayed:



- ✓ After the \*740 (babysitter) has been activated, the proprietary phone display shows the following message:




### 5.1.2 Phonebook in digital proprietary phones

The server offers for digital proprietary phones the <LIST> phonebook divided into personal and global phonebooks.

The personal <YOUR> phonebook contains 32 numbers and the <EXT> phonebook of the server extension users.

The global <GLOB> phonebook may contain up to 3,000 entries and may be edited by authorised users from their telephones, through User Zone and in the configuration program.

Apart from that, the server provides a <HIST> call log divided into incoming <IN> and outgoing <OUT> calls, each capable of storing up to 8 numbers.



The history of missed calls is displayed after the **HIST** button is pressed. Then, the

call type (incoming <IN> or outgoing <OUT>) is specified. The cursor can be scrolled up and down using the navigator keys (arrows or knob). The current cursor position is indicated by the ">" symbol. Using the **CALL** button, you may get a connection with the dialled number. The "<<" button makes it possible to go one level higher – in this case, it is the selection of missed call types.

To open the directory, you must press the <**LIST**> button. This provides you with the following options:

**The <EXT> extension list** is downloaded from the current server configuration and numeration plan. The records are scrolled up and down by means of navigator keys.

**The < - >** button is used to move quickly and to search for users based on their descriptions. When this button is pressed together with e.g. letter <**P**> (button + 7), the cursor instantly moves to the first description in the directory starting with the letter "P." You may also enter the first several letters of the name. The **HOLD** button functions in this case as the BACKSPACE, i.e. it deletes the entered letters. The <**1**> button functions as the SPACE. The "<<" button is used to go one level higher – in this case, it is the selection of contacts. You may also call the selected user by pressing the **CALL** button.

You create the <**YOUR**> personal phonebook yourself. In order to add a new one or edit the existing number, select the right position, press the **EDIT** button and:

- enter the contact description using the keypad and confirm it by pressing the **OK** button,
- enter the number using the keypad and confirm it by pressing the **OK** button.

A given record has been added or edited. In order to delete a given record, select the desired number, press the **EDIT** button and press the **OK** button twice. The record has been deleted.

The personal phonebook may also be managed via the computer [program](#). The description can be found in the *ProximaWeb/LibraWeb program operation manual*.

Global <**GLOB**> phonebook is designed for all proprietary phones. In order to add a new one or edit the existing number, select the right position, press the **EDIT** button and:

- enter the contact description using the keypad and confirm it by pressing the **OK** button
- enter the number using the keypad and confirm it by pressing the **OK**

button.

A given record has been added or edited. In order to delete a given record, select the desired number, press the **EDIT** button and press the **OK** button twice. The record has been deleted.

The global phonebook may also be managed via the User Zone and LibraWeb computer **program**. The description can be found in the *ProximaWeb/LibraWeb program operation manual*.

### **5.1.3 Programming buttons and LEDs in the digital proprietary phone**

Digital proprietary phones offer the possibility of defining the functions of programmable keys (speed dialling). In the case of Panasonic digital proprietary phones, programmable line keys are numbered starting with 1.

In order to programme the line keys and the LEDs ascribed to them:

1. Enter the programming mode by pressing the **PROGRAM** button.
2. Press the selected key and enter the preview mode. The LED corresponding to the programmed button will go on. After the button has been pressed once, the button settings will be shown on the display. After the button has been pressed twice, the settings of the corresponding LED will be displayed.
3. By pressing the **STORE** button in the preview mode, you enter the mode in which you may define the button or LED settings.
  - a) When assigning the trunk line, you should enter the trunk line number, e.g. **\*801\*2\*3#** (3rd port in the trunk line card installed in the second slot of the first server unit), both for the button and for the LED. The button will then signal the call traffic (status) within this trunk line.
  - b) When assigning the extension number, you should enter the selected user's number, e.g., **110** for the button and **110** for the LED. The button will then signal the call traffic (line status) for the **110** extension. The comma mark is entered using the **FLASH** button.



It is recommended to enter the comma before the number in the button settings. As a result, a direct, single-button call transfer for a given user will be possible.

After the correct data has been entered, the server should recognise the extension number active within the server and confirm the changes automatically. If this is not the case, confirm the changes by pressing the **STORE** button.

In the course of programming, the **HOLD** button functions as the BACKSPACE. It may be used to delete the digits entered by mistake.



The server makes it possible to capture a call directly from the proprietary phone and console speed dialling buttons. However, it is required for the called number to be defined “under” the speed dialling button.

#### **5.1.4 Direct Station Selection (DSS) console – key functions (Libra PBX Server only)**

The Direct Station Selection (DSS) console makes it possible to observe the line status and the connection with the server user by means of a single button.



If a given extension user is engaged, e.g. is having an outgoing or incoming call, the key ascribed to them will be backlit red. If a server user is idle, the button will not be backlit.

If you press a console button representing an idle user line (without picking up the phone), the speakerphone (linked with this console) will be activated within the proprietary phone (the AutoSpeaker option should be switched on in the computer [program](#)).

#### **Front panel of the KX-DT590 DSS console**

To each DSS console key and busy lamp field (BLF) as well as to each function key and to F1-F16 LEDs, an extension or outside party’s number or any sever function may be assigned.

The method of programming keys and BLFs using the telephone is described later in this section. The description of the procedure of programming keys and LEDs within proprietary phones and consoles using the computer program is described in the *LibraWeb program operation manual*.

The backlight colour provides information about the line status:

<b>idle line:</b>	<b>no backlight</b>
<b>outgoing call:</b>	<b>continuous red light</b> – the extension line is being used by the user, the server services are being used;
<b>incoming call:</b>	<b>flashing red light</b> – a given extension is being called; <b>continuous red light</b> – the call has been answered and is being held.

### **5.1.5    *Messages on the digital proprietary phone display***

Proprietary phone displays sometimes show messages informing the user, among others, about the caller's number or about the number of the trunk line through which a connection is established by the server.

#### **Messages may be divided in the following manner:**

- messages displayed when the phone is hung up,
- messages displayed during an incoming call,
- messages displayed during an outgoing call.

Messages are written in the Latin alphabet. Polish letters with diacritics are automatically changed into the similar ones found in the Latin alphabet (ą into a, ę into e..., etc.).

#### **MESSAGES DISPLAYED WHEN THE PHONE IS HUNG UP**

- ✓ Date, time and the server operation mode:



18 May 10:36 B

- ✓ If somebody tried to call you while you were away, a message about the recent missed call will be displayed: – message about the caller (or about the trunk line), date and time of call. The following messages are displayed interchangeably:



Ext 11 called



on DD at HH:MM

- ✓ After the [\\*740](#) (babysitter) and the [\\*760](#) (do not disturb) functions have been activated, the proprietary phone display shows the following messages respectively:



## MESSAGES DISPLAYED DURING AN INCOMING CALL

- ✓ In the case of a call from a server user, the display shows their name (extension line description) and the extension number:



- ✓ In the case of a call from an outside party and provided that the server operates in the [DISA](#) mode, the display shows the information about the trunk line number from which the call is coming (xx – trunk line number):



- ✓ In the case of a call from an outside party and provided that the server operates in the [Announcement](#) mode, the display shows the information about the external number ([CLIP](#)) or, if the CLIP is unavailable, information about the trunk line number from which the call is made (xx – trunk line number):



- ✓ If the [HOLD](#) function was activated when resuming the call after the time defined in the computer program, the following message is displayed:



- ✓ In the case of a call from the door phone, the display shows a suitable message along with the assigned extension number. If the doorphone terminal has no number assigned, 0 will be displayed instead of the number.



where XX stands for the number ascribed to the terminal in the computer [program](#).

## MESSAGES DISPLAYED DURING AN OUTGOING CALL

- ✓ When the called party picks up the phone, the proprietary phone activates the call timer. Information about the call duration is displayed:

**HH : MM : SS**

- ✓ When the telephone (\*92 function) or with any (\*94 function) external number is being established, the display shows the following message:

**\*\*Auto dial\*\***

- ✓ When you dial the number, the dialled digits are displayed one by one. This option makes it possible to ensure that the dialled number is correct.

### 5.1.6 Programming buttons and LEDs using the telephone

The server allows the individual programming:

– of **direct dialling buttons**:

CO1÷CO24 in the case of the proprietary phone and S1÷S60 in the case of the console (Libra only).

– of **direct dialling button LEDs (BLF)**.

Thanks to this function, you can quickly access both trunk and extension lines from the proprietary phone or from the console. Apart from that, it provides visualisation of the line engagement status and a single-button access to the selected functions described above.

## PROGRAMMING COn and Sn DIRECT DIALLING BUTTONS AND THEIR LEDs

All COn and Sn buttons of a proprietary phone and console may be ascribed to either trunk (CO) or extension (user) lines. The same applies to LEDs next to each button.

Before programming, make sure that the proprietary phone is not blocked with a PASSWORD. The phone should be hung up (idle user).

## If you wish to activate the programming mode:



Press the **PROGRAM** button

The following message will be displayed: **PROGRAMMING**



Selection of any button is signalled with a double beep.

By pressing the **COn** button in the telephone or the **Sn** button in the console **once**, you may view the currently ascribed extension user or trunk line numbers. By pressing the button **twice** you may view the extension user or the trunk line number ascribed to this button's LED.

It is recommended for the settings of a given button to be the same as the settings of the corresponding LED.

## If you wish to change the settings of the trunk or extension line for a given button or COn/Sn:



Enter the [programming](#) mode:



Push the programmed button – once if you want to change the button settings or twice if you want to change the settings of the LED assigned to this button.



Dial the correct number (e.g. \*801\*2\*4# – a trunk line in the first unit, second slot, 4th card port or e.g. ,117 – an extension number). The <comma> mark is entered using the **FLASH** button.



It is recommended to enter the comma before the number in the button settings. As a result, a direct, single-button call forwarding for a given user will be possible. **The comma should be omitted as far as the LED settings are concerned.**



When the proprietary phone buttons are being programmed, the LED is flashing green.

When the console buttons or the proprietary phone/console LEDs are being programmed, the button LEDs are flashing red.



Press the **STORE** key to confirm the entered data. You will hear a double beep and then, the programmed number will be displayed.



Programme the other buttons in the same way or press the **PROGRAM** button again to exit the programming mode.



If the programmed user's number has been ascribed to another button before, the previous setting will be cancelled. Thanks to this functionality, you may programme the buttons without the need to delete the repeated ports.

#### If you want to delete the assignment settings without assigning the number:



Enter the [programming](#) mode:



Press a given button once if you want to remove the number assigned to the button or twice if you want to remove the number assigned to the LED.



Press **STORE**.

You will hear two beeps and the **Removed** message will be displayed.



Press the **PROGRAM** button again to exit the programming mode.

Programming the proprietary phone LEDs takes place after a given trunk button has been pressed twice in the programming mode. The flashing LED will turn red (the LED is green when the trunk button is being programmed after it has been pressed once).

When programming the proprietary phone CO1 ÷ CO24 and the console S1 ÷ S60 buttons and LEDs, you dial the extension or the trunk line (CO) number consistent with the current configuration. The server saves the assignment of buttons and LEDs to proper ports.

If you send the current configuration including the new extension enumeration (or the access codes to trunk lines) to the server via the computer program, the settings of the proprietary phones and DSS consoles will be changed automatically.

## 6. Doorphones for the Proxima and Libra servers

The server **Doorphone** function is used to support the line connected to the doorphone device (*with additional equipment: doorphone case, latch*). Via this line, the server user may remotely (using the telephone) open the entrance gate or talk to the people who wish to enter the company premises.

The server supports the PLATAN DB07 doorphone. A doorphone must be installed according to the documentation supplied with each device.

## 7. Voicemail

The server has a built-in voicemail which may be activated by either selected or all server users. **Voicemail configuration is carried out in the computer program.**

### General description

- users' personal inboxes
- recording messages from internal and/or external users
- total memory capacity for announcements and voicemail within the server: **up to 30 hours;**
- notifications about new messages
- inbox access password
- built-in announcements
- individual inbox configuration by users via the voice menu
- two inbox operation profiles
- taped messages.

### 7.1. Using voicemail

#### 7.1.1 *Voicemail initiation*

In order to use the server voicemail, the conditions described in the “Voicemail” section of the ***ProximaWeb/LibraWeb program operation manual*** must be met. The voicemail is active by default.

#### 7.1.2 *Forwarding calls to a voicemail inbox*

If the voicemail is active, the user may forward the calls to their personal voicemail inbox (ascribed to the extension number). A call may be forwarded to the voicemail inbox with the **TEL** access number:

- immediately without sending the information about this call to the telephone (*the \*734 TEL function is on – “unconditional call forwarding to TEL”*),
- when busy (*the \*736 TEL function is on – “call forwarding to TEL when my number is busy”*)
- when no answer (*the \*737 TEL function is on – “call forwarding to TEL when MY number fails to answer”*)
- when VoIP phone not reachable (*the \*738 TEL function is on – “call*

*forwarding to TEL when MY VoIP phone is not reachable”).* The function is executed when:

- the VoIP extension is logged out
- 100/Proceeding answer
- no answer (eg. phone disconnected).

In order for the voicemail inbox to be called as described above, call forwarding to the voicemail local access number must be set. Voicemail access number (*dialogue box: Extensions → Voicemail → Global settings*) and forwardings (*dialogue box: Extensions → Call forwarding*) are configured in the computer [program](#). Call forwarding may also be programmed using the telephone (see: [Call forwarding...](#)).

### 7.1.3 Calling a voicemail inbox

**The server directs the call to your extension number.**



If your voicemail inbox is active and call forwarding to the voicemail box has been set, the call will be forwarded.



**After the voicemail inbox has been called, the calling party hears a welcome announcement** – either a standard one or recorded by the user. A standard welcome announcement is as follows:

*“You are connected to the voicemail ....*

*Please, leave your message after hearing the bip.*

*Hang up as soon as you’re done.”*



**Then, a single tone is generated and the message starts to be recorded.**

The message registering process may be deactivated. In such a case, the voicemail box will play taped messages. When the user is absent, e.g. information about the possible method of contact at a given moment may be played.



It is possible to register the connection attempt. The voicemail box records such an occurrence as a new message. When the message is being listened to, information that the user has left no message is played.

**Notes:**

- while the message is being recorded, no digits should be dialled; otherwise, the recording process will end and the “unavailable tone” will be heard,
- if the maximum recording time limit is exceeded, the recording process ends with an “unavailable” tone (the message recorded up to that moment is saved),
- if a voicemail box is called from the door phone, the recording process ends after the door phone key has been pressed again or after the exceeding of the maximum recording time limit, signalled with a short “unavailable” tone,
- a voicemail inbox may be called if a user has been granted adequate privileges, an inbox is enabled and is not engaged (if any of the conditions listed above is not met, the server functions as if the box was off).
- if a user with the function of call forwarding to a voicemail set belongs to a Hunt Group, call forwarding to this user's voicemail inbox is not executed if the Hunt Group is called.

***7.1.4 Information about new messages***

Information about new messages (since the last playback/notification) in a voicemail inbox is generated only if the function is activated for a given user in the computer program. The program offers the following methods of notification about new messages or connection attempts:

- the voicemail box rings after the first hanging up of the phone (it is obvious that the user is near the telephone).
- the voicemail box rings at the defined times and with the set frequency – this option is recommended if the user rarely uses the phone.

Voicemail notifications are carried out in the form of phone ringing (calling rhythm) and messages sent onto the proprietary phone display. If you pick up the phone during the notification process, a connection with the voicemail box will be established. After the call, you may use the [Voicemail Menu](#).

**Notes:**

- notifications are not generated if the phone has the “Do not disturb” function activated,
- notifications cannot be captured from another telephone; any capturing attempts will result in the “unavailable” tone,
- the voicemail message notification time is configured in the computer

program; default setting – 20 seconds.

### 7.1.5 Direct access to a voicemail box

Connection with the voicemail may be established by dialling any of the two voicemail box access numbers. Both numbers are to be defined in the computer program and should be provided to the user by the installer.

- the first number enables **local access**, i.e. access using your own telephone;
- the second number enables **remote access**; after this number, the extension number and the password have been entered, access to the authenticated user's voicemail box is granted using an extension telephone other than your own one or from the external line.

#### ACCESS TO A VOICEMAIL BOX – LOCAL

You are either calling using your own telephone or are logged in as a virtual user.



Pick up the phone.



Enter the voicemail **local access number**.



If the local access password is set, you will hear the following message:

*“Enter your voicemail password and press #”*



Enter the required password and press #.



You are now in your personal voicemail box – Voicemail Menu [main level](#).

#### ACCESS TO A VOICEMAIL BOX – REMOTE

You are calling through a trunk line or using any telephone connected to the server.



Pick up the phone.



If you are calling from the outside, call the server external number and while in the **[DISA](#)** mode, enter the voicemail **remote access number**.

If you are calling using an extension phone, enter the **remote access number**.



When you hear a continuation tone, **dial YOUR extension number**.



You will hear the following message:

*“Enter your voicemail password and press #”*



Enter the required password and press #.



You are now in your personal voicemail box – Voicemail Menu [main level](#).

Access to your own voicemail box is granted after the personal password has been entered. You may enter 4 to 8 digits. After you have entered the last digit, press “#.” The password is set by default to “1234,” so it is recommended to change the access code using the telephone or the computer program. When changing the password, you may also deactivate it by pressing “#” without entering any digits before.

#### Notes:

- if you enter an invalid password or if the time limit for entering of the password is exceeded, you will hear an “unavailable” tone,
- a voicemail inbox may be called if a user has been granted adequate privileges, an inbox is active and is not engaged and if 1 of 25 voice channels is idle (if any of the conditions listed above is not met, the server functions as if the box was off).

#### 7.1.6 *Voicemail connection (main menu level)*


After you have *called* your personal voicemail inbox, you will be informed about the number of new and saved messages. Next, depending on whether there are any new messages or not, you will hear either the main menu options or the new messages. The main menu is played back twice. After that, you will hear a goodbye message and the connection with the voicemail will be ended.

**Notes:**

- if any other digit (than those supported in this menu) is entered, the voicemail ignores it,
- a voicemail inbox may be called if, among others, a user has been granted adequate privileges, a inbox is active and is not engaged and if 1 of 25 voice channels is idle (if any of the conditions listed above is not met, the server functions as if the box was off).
- if a voicemail inbox is full, the following message is heard (before the information about the number of messages):

*"Your voicemail box is full"*

The voicemail box main menu flow chart is presented below:



### 7.1.7 Listening to voicemail messages


The flow chart presented below applies to the basic profile and to the default settings of deleting voicemail messages.

**Notes:**

- a new message may be either deleted (7) or saved (8) when it is being listened to,
- you may instantly delete the saved message when listening to it,
- a new message may also be deleted while or after listening to it,
- if no message has been recorded, the following information can be heard: "No new messages left."



If more than one message has been recorded, the last one is played first.



### **7.1.8 Listening to voicemail messages – profiles**

The server makes it possible to select the voicemail box operation profile. The standard profile is designed for beginners, while the advanced profile – for more experienced users. The differences between the standard and the advanced profile are presented below.

The voicemail box operation profile may be changed using the telephone. What you must do is to enter your personal voicemail box and use **MENU: PERSONAL SETTINGS**

FUNCTION	BASIC PROFILE	ADVANCED PROFILE
Presentation of date, time and the number of the caller that left the message	X	
Deactivation of hints about the keys in the voicemail menu		X
Automatic presentation of new messages	X	X
Presentation of information about the keys in the personal settings access menu	X	X

### **7.1.9 Displaying date, time and caller's number**

Information about the date and time at which the message was left and about the caller's number is made up of several messages. The date is composed of the day and the month.

The information is presented in the following format:

“date ... time ... number [extension\external] [...]unknown]”

e.g.

“the second of August at twelve forty one unknown external number”

“the twenty fifth of February at eight twenty one number five eight five five five eight eight zero zero.”

### **7.1.10 Returning calls**

While listening to the recorded message, it is possible to call back the caller that has left it. In the case of returning a call, the voicemail box is exited automatically.

In order to call back the caller that have tried to call you you and/or left you a message, press **1** while listening to the message.

(See: [MENU: WHILE LISTENING TO MESSAGES](#))

### Notes:

- returning a call is possible provided that the server can recognise the number of the caller that has left the message (extension number or external CLIP),
- the privileges of the user calling a voicemail box are maintained.

## 7.2 Voicemail menu

### 7.2.1 MENU: While listening to messages

<b>1</b>	Return call
<b>2</b>	Day on which the message was left
<b>3</b>	Number of the caller that left the message
<b>4</b>	Previous message
<b>6</b>	Next message
<b>7</b>	Delete message
<b>8</b>	Save message
<b>9</b>	Delete all heard messages
<b>0</b>	Information about active keys
<b>*</b>	Return to main menu

### 7.2.2 MENU: Personal settings

**1** Voicemail password change



New password confirmation



Cancellation without any changes

**2** Welcome message change



Personal welcome message recording



Personal welcome message listening



Cancel

**3** Message listening profile selection



Profile change



Cancel

**7** Activation or deactivation of connection attempt notification



Activation/Deactivation



Cancel

**8** Activation or deactivation of message recording



Activation/Deactivation



Cancel

**9** Activation or deactivation of voicemail



Activation/Deactivation



Cancel



Return to main menu

**Notes:**

- menu level change is signalled with a sound,
- if the message recording is deactivated, it is recommended that a personal welcome message with suitable information for the caller be recorded, e.g.  
*I'm away on holiday...in the case of an important business matter, please call...*
- in order to record a personal welcome message, use *Menu: Personal settings*
- entering the main menu is signalled with a different sound.

## 8. Acoustic signals

Acoustic signals in the PROXIMA and LIBRA server

Description	Attribute	Number of signals
Server activation	- - -	3
Extension user earth fault	C -	1
Trunk line damage	- -	3
No supply voltage or fan seizure	DO	4
Long-lasting power supply unit damage (after 3 attempts to switch it on)	DO	12

**where:**

- C - - Cyclical rhythm every 2 s
- D - - Cyclical rhythm every 4 s

## 9. User Zone

Each extension user has access to the *User zone* from the web browser level. The *User Zone* allows you to verify:

- call forwarding settings,
- Hunt Group settings,
- voicemail status,
- outgoing and incoming call log,
- access codes to server functions.

To invoke the *User Zone*, enter the Proxima or Libra server IP (by default: 192.168.1.250) in the browser address bar.



The login box will be displayed. Enter the user's extension number and the password (telephone block code).

<b>User logging in</b>	
Extension no.:	<input type="text" value="108"/>
Access code:	<input type="password" value="*****"/>
<input type="button" value="Log in"/>	

Platan 2012 - v0.02.05      [Go to administration mode](#)

When logged in, you have access to three tabs:

- *Configuration*,
- *Call history*,
- *Help*.



A proprietary phone user with the global phonebook assigned has the access to the fourth bookmark: *Global phonebook*.



## 9.1 User Zone – Configuration

A user can view the following settings in the *Configuration* tab:

 A detailed screenshot of the Libra User Zone Configuration tab. The interface is divided into several sections:
 

- My profile:** Shows Extension no.: 108, MSN/ODI number, and Description: John Smith.
- Hunt Groups:** Shows Sales - no. 601 - logged in.
- Call forwardings:** Shows Unconditional call forwarding to number: none, Call forwarding when no answer for 5 seconds to number: none, and Call forwarding when busy to number: 152.
- Voicemail:** Shows Status: enabled, New messages: 0, All messages: 0, and Limit of messages: 15.
- Basic settings:** Located at the bottom left.
- Call forwarding settings:** Located at the bottom center.
- Information about the assignment to Hunt Groups and the current status: logged in/out:** A red box highlights the Hunt Groups section.
- Voicemail status:** A red box highlights the Voicemail section.

 Red arrows point from the labels 'Basic settings' and 'Call forwarding settings' to their respective sections in the configuration page.

## 9.2 User Zone – Call history

In the *Call history* tab, a user can view outgoing and incoming call history in the current and previous month.

**PLATAN Libra User Zone**

John Smith | [Log out](#)

[Configuration](#) | [Call history](#) | [Global phonebook](#) | [Help](#)

Type [outgoing \(O\)](#) | [Previous month](#)

Type	No.	Date	Hour	Duration
(I)	383997475	2012-02-09	13:40	00:00:12
(O)	585558834	2012-02-09	13:38	00:00:42
(O)	587503305	2012-02-09	13:31	00:00:14
(O)	587503305	2012-02-09	13:29	00:00:07
(O)	587503305	2012-02-09	13:28	00:00:20
(O)	587503305	2012-02-09	13:27	00:00:06
(O)	587503305	2012-02-09	13:26	00:00:07
(O)	587503305	2012-02-09	13:24	00:00:05
(O)	585558800.234	2012-02-08	08:32	00:00:15
(O)	585558800.234	2012-02-08	08:31	00:00:07
(O)	383997475	2012-02-08	10:01	00:00:33
(O)	5001#	2012-02-01	10:20	00:01:07
(O)	800240240	2012-02-01	09:41	00:00:02
(O)	800240240	2012-02-01	09:38	00:00:03

Platan 2012 - v0.02.05

[Go to administration mode](#)

## 9.3 User Zone – Global phonebook

In the *Global phonebook* bookmark a proprietary extension user with the global phonebook assigned can look through the entries in the phonebook, and with the edition privileges can add, change and delete entries.

**PLATAN Libra User Zone**

John Smith | [Log out](#)

[Configuration](#) | [Call history](#) | [Global phonebook](#) | [Help](#)

Number of records per page: [50](#) | [First](#) | [Previous](#) | [Next](#) | [Last](#)

Position	Description	Number	Save	Cancel	Delete
New					
1	CONDOLESA MARGQUIEZ	0489856265			<a href="#">Delete</a>
2	MARTIN JONES	0508508508			<a href="#">Delete</a>
3	PLATAN POLAND	00048585558800			<a href="#">Delete</a>
4	SERENA WILLIAMS	0501450480			<a href="#">Delete</a>
5	VENUS THOMPSON	0654123852			<a href="#">Delete</a>

Platan 2012 - v0.02.05

[Go to administration mode](#)

## 9.4 User Zone – Help

The *Help* tab contains a shortened list of the current Proxima or Libra server functions.

If the default settings had been changed by the installer, the information about the current functions dial numbers will be presented in the *User Zone → Help* as well.

The screenshot shows the Libra User Zone interface with the 'Help' tab selected. The title bar includes the PLATAN logo, the word 'Libra', and 'User Zone'. On the right, there is a user profile for 'John Smith'. Below the title bar is a navigation bar with tabs: Configuration, Call history, Global phonebook, and Help (which is highlighted). The main content area is titled 'Shortened list of PBX server functions' and contains a detailed list of function descriptions and their dial numbers:

- 10 - 9969 dialing of an extension's number, dialing of a Hunt Group or a radio control number;
- # XX speed dialing;
- 0 external call;
- \*0 a\*b\*c# external connection through 'aux' line, where a - unit number, b - slot number, c - port number on the card;
- \*1 1 to \*4 external call through a given trunk group;
- 0 busy tone 0 booking of an access to a busy external (CO) line;
- \*0 0 a\*b\*c# busy tone 0 booking of an access to a specific busy external (CO) line, „TEL“ busy tone 0 booking of a call to a busy extension to the „TEL“ number;
- \*0 redialing of the most recently dialed external number;
- \*2 establishing of a connection with the most recently dialed external number;
- \*3 4 XXXXX establishing of a connection with the external number XXXXX;
- \*3 4 cancellation of \*92, \*94 and \*96 services;
- \*5 „b1n“, „m1n“, „TEL“ establishing of a connection with any external number at a specified time;
- \*997, \*998, \*999 direct access to emergency telephone numbers;
- \*7 0 1 x listening to the voice announcement no. xx;
- \*7 1 „TEL“ call capturing;

## 10. Short list of server functions

Function	Page no. in the Manual	Function description
<b>1 - 9999</b>	(13) (41)	dialling an extension number dialling a Hunt Group or a broadcasting system
# XX	(46)	speed dialling
<b>0</b>	(14)	external call through a main trunk lines bunch
<b>*96</b>	(37)	external call through a main trunk lines bunch with CLIR enabled
<b>*8 0 a*b*c#</b>	(36)	external call through a specific trunk line
<b>*8 1 to *84</b>	(36)	external call though a specific trunk lines bunch
<b>0 engaged tone 0</b>	(39)	booking access to an engaged trunk line
<b>*8 0 a*b*c# engaged tone 0</b>	(46)	booking access to a specific engaged trunk line
<b>“TEL” engaged tone 0</b>	(40)	booking a call to an engaged extension user with the “TEL” no.
<b>*9 0</b>	(42)	redialling the last dialled external number
<b>*9 2</b>	(43)	booking a call to the last dialled external number
<b>*9 4 xxxx</b>	(44)	making a call to any external xxxx number
<b>*9 4</b>	(43)	canceling *92, *94 and *95 services
<b>*9 5 “hh” “mm”“TEL”</b>	(45)	booking a call to any external number at a specified time
<b>112, 997, 998, 999</b>	(36)	direct access to emergency telephone numbers
<b>*85</b>	(54)	conference room reservation
<b>*86</b>	(56)	entrance to the conference room
<b>*7 0 1 x x</b>	(72)	listening to the announcement no. xx
<b>*7 1 “TEL”</b>	(27)	call capturing
<b>*7 1 “myTEL”</b>	(27)	returning an unanswered internal call
<b>*7 1 0</b>	(28)	external call capturing
<b>*7 2 “TEL”</b>	(60)	CIRCULAR conference
<b>*7 3 0 xxx 0</b>	(33)	logging a user out of the Hunt Group
<b>*7 3 0 xxx 1</b>	(33)	logging a user into the Hunt Group
<b>*730 0 0</b>	(33)	logging out of all groups
<b>*7 3 1 “T” “hh” “mm”</b>	(61)	“wake-up call” (single)

<b>*7 3 2 "T" "hh" "mm"</b>	(61)	"wake-up call" (multiple) booked wake-up call off
<b>*7 3 3</b>	(61)	unconditional call forwarding to "TEL" (I'm there)
<b>*7 3 4 "TEL"</b>	(28)	unconditional call forwarding off
<b>*7 3 4</b>	(28)	unconditional call forwarding from "TEL" to me ("I'm here")
<b>*7 3 5 "TEL"</b>	(29)	unconditional call forwarding to "TEL" when my number is busy
<b>*7 3 6 "TEL"</b>	(30)	"when busy" call forwarding off
<b>*7 3 6</b>	(30)	call forwarding to "TEL" when no answer for 20 s
<b>*7 3 7 "TEL"</b>	(31)	call forwarding to "TEL" when no answer for "tt" time
<b>*7 3 7</b>	(31)	"when my number fails to answer"
<b>*7 3 8 "TEL"</b>	(33)	call forwarding off
<b>*7 3 8 "TEL" # „tt”</b>	(33)	call forwarding to "TEL" when my VoIP phone not reachable for 20 s
<b>*7 3 8</b>	(33)	call forwarding to "TEL" when my phone not reachable for "tt" time
<b>*7 3 8</b>	(33)	"when myVoIP phone not reachable"
<b>*7 4 0</b>	(66)	call forwarding off
<b>*7 4 1 xxx</b>	(72)	"babysitter" on
		listening to an announcement or to a melody ('xxx' – annouc. or melody number)
<b>*7 4 2</b>	(62)	operation mode A
<b>*7 4 3</b>	(62)	operation mode B
<b>*7 4 4</b>	(62)	operation mode C
<b>*7 4 5</b>	(62)	operation mode D
<b>*7 4 6</b>	(62)	operation mode E
<b>*7 4 7</b>	(62)	operation mode F
<b>*7 6 4</b>	(62)	switching off the automatic change of server operation modes
<b>*7 6 5</b>	(62)	switching on the automatic change of server operation modes
<b>*7 6 0</b>	(66)	"do not disturb" on
<b>*7 6 1</b>	(66)	"do not disturb" off
<b>*7 6 2</b>	(79)	hands-free headset on
<b>*7 6 3</b>	(79)	hands-free headset off
<b>*7 7 "TEL" "code"</b>	(49)	logging a virtual extension for a single call (TEL – your extension number)
<b>*7 8 0 "code"</b>	(48)	unlocking external calls
<b>*7 8 1 "code"</b>	(48)	blocking external calls
<b>*7 8 2 "TEL" "code"</b>	(47)	user logged into a given port until cancellation, user is granted the "TEL" user privilege
<b>*7 8 3 "code"</b>	(47)	virtual user logged out, *782 function off
<b>*7 8 4 "TEL" "code"</b>	(47)	virtual user logged in as in the case of the *782 function;

		however, after the time limit specified in the program, they will be logged out automatically
<b>*7 8 5 xxxx yyyy #</b>	(48)	block code change
<b>*7 9 "TEL"</b>	(42)	message onto the proprietary phone speaker
<b>*89 x "TEL"</b>	(46)	saving an individual short number
<b>*91 x</b>	(46)	dialling an individual short number
<b>FLASH "my TEL"</b>	(23)	hold – putting the call “on hold”
<b>FLASH "TEL"</b>	(20)	external call transfer to an extension user with the “TEL” number
<b>FLASH "TEL"</b>	(21)	return (consultative) call from an extension user with the “TEL” number
<b>FLASH "TEL" 3</b>	(22)	offering an external call to an engaged extension
<b>FLASH "TEL" *7</b>	(24)	adding an extension user /outside party with the “TEL” number to an ongoing conversation – conference call)
<b>FLASH 0</b>	(20)	resuming a call with the transferred user
<b>FLASH * 1</b>	(60)	analogue FLASH on trunk lines
<b>*748</b>		listening to the server driver number using the telephone
<b>*749</b>		listening to the server IP number using the telephone
<b>Return external call</b>	(25)	
<b>Conference with outside parties</b>	(24)	
<b>Transferring an external call to another trunk line</b>	(24)	

### In the server programming mode

<b>41 “IP address” #</b>	(70)	setting up the server IP address (e.g. 41 192*168*1*198#) <b>(the server will restart after the programming)</b>
<b>42 “network mask” #</b>	(70)	programming the network mask (e.g. 42 255*255*255*0#) <b>(the server will restart after the programming)</b>
<b>2 9 x x</b>	(71)	recording announcement using the telephone (xx – announcement number from the range of 01-99)

<b>6 0 HH MM SS</b>	(73)	clock setting in the server
<b>6 1 HH MM SS T</b>	(73)	date setting in the server
<b>81</b>	(74)	deleting active bookings in the server
<b>Special codes</b>	(74)	special service functions

## 11. Glossary

**DTMF** (*Dual Tone Multi Frequency*) is the name of tone signalling used in telephone devices. It is also known as *TouchTone®*. DTMF is an example of MFSK (Multiple Frequency Shift Keying).

**DISA** (*Direct Inward System Access*) is the name of a functionality offered by PBX telecommunications systems, enabling you to call an extension user without going through an operator.

Having connected with a given PBX server, a user hears a announcement recorded by the server's owner and while or after listening to it, dials the desired extension number using a telephone with DTMF tone dialling.

A drawback of this system is that the caller pays for the call from the moment the DISA device answers the phone, i.e. they pay for the time that passes until the phone is answered after the extension number has been dialled.

**DDI** (*Direct Dial-In* (Europe) or *Direct Inward Dialing* (USA)) is the name of a function offered by PBX servers, enabling you to call an extension user directly.

A PBX server user is provided by the operator with at least 10 telephone numbers and each of them is assigned to individual server extension users. For example, in the case of 7-digit numeration, a user receives 100 numbers in the 1234500-1234599 range. 12345 functions then as the server number, while the last two digits are used as the number of an extension user. DDI numeration using the last one or the last three digits is also possible (a user may then receive either 10 or 1000 numbers). A connection between the server and the operator's exchange is most often established using an ISDN line.

DDI offers the following advantages:

It makes the server operator's assistance no longer necessary and eliminates the need of using an additional extension number.

It is also cheaper than buying from the operator a separate telephone line for each extension user. For example, you pay the operator for a few lines only and have 100 DDI numbers at your disposal.

**CLIP** (*Calling Line Identification Presentation*) is a service that consists in presenting the caller's number on the telephone display (or on a special telephone snap-in's display). This service is available for both land line and mobile networks.

**CLIR** (*Calling Line Identification Restriction*) is a service that blocks the presentation of the caller's number. Thanks to this functionality, the number of the user initiating the call will not be shown even if the other party has the CLIP function on.

**Prefix** (or **prefix**) is a string of digits following the 10XX or 10XXX pattern (where X stands for any digit), identifying a given telecommunications operator. Telecommunications operators and the calls made by their customers are identified within the telecommunications networks by means of assigned prefixes. Prefix is officially referred to as the network access number. In a sense, prefixes enable communication between customers and telecommunications networks (owned by telecommunications operators). By choosing a given prefix, a customer chooses the operator through the network of which a call is to be carried out.